



# AmI TX-AL-I

## User's Manual

Thin Mini-ITX Embedded Motherboard with  
Intel® Atom™, Pentium®, and Celeron® SoC



|                  |                  |
|------------------|------------------|
| Manual Revision: | 0.10 preliminary |
| Revision Date:   | April 6, 2017    |
| Part Number:     | 50-1J087-1000    |

Leading **EDGE COMPUTING**

## Revision History

| Revision | Description         | Date       | By |
|----------|---------------------|------------|----|
| 0.10     | Preliminary release | 2017-04-06 | JC |

## Preface

Copyright 2017 ADLINK Technology, Inc.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

### Disclaimer

The information in this document is subject to change without prior notice in order to improve reliability, design, and function and does not represent a commitment on the part of the manufacturer. In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

### Environmental Responsibility

ADLINK is committed to fulfill its social responsibility to global environmental preservation through compliance with the European Union's Restriction of Hazardous Substances (RoHS) directive and Waste Electrical and Electronic Equipment (WEEE) directive. Environmental protection is a top priority for ADLINK. We have enforced measures to ensure that our products, manufacturing processes, components, and raw materials have as little impact on the environment as possible. When products are at their end of life, our customers are encouraged to dispose of them in accordance with the product disposal and/or recovery programs prescribed by their nation or company.

AmITX-AL-I is a RoHS compliant and lead-free product

### Trademarks

Product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective companies.

## Table of Contents

|   |           |
|---|-----------|
| <b>Revision History .....</b>                       | <b>2</b>  |
| <b>Preface.....</b>                                 | <b>3</b>  |
| <b>1. Introduction .....</b>                        | <b>7</b>  |
| 1.1.    Packing List .....                          | 8         |
| 1.2.    Optional Accessories .....                  | 8         |
| <b>2. Specifications.....</b>                       | <b>9</b>  |
| 2.1.    Core System .....                           | 9         |
| 2.2.    Rear I/O Connectors .....                   | 9         |
| 2.3.    Internal Headers and Connectors.....        | 9         |
| 2.4.    Form Factor .....                           | 10        |
| 2.5.    SEMA Board Controller.....                  | 10        |
| 2.6.    Debug Header .....                          | 10        |
| 2.7.    Video.....                                  | 10        |
| 2.8.    Audio.....                                  | 10        |
| 2.9.    LAN.....                                    | 10        |
| 2.10.    Power Specification .....                  | 11        |
| 2.11.    Temperatures .....                         | 11        |
| 2.12.    Environmental .....                        | 11        |
| 2.13.    Operating Systems.....                     | 11        |
| 2.14.    Functional Diagram.....                    | 12        |
| <b>3. Mechanical Layout .....</b>                   | <b>13</b> |
| 3.1.    Connector Locations .....                   | 13        |
| 3.1.1.    Rear I/O .....                            | 13        |
| 3.1.2.    Top Side Connectors.....                  | 13        |
| 3.1.3.    Bottom Side Connectors.....               | 14        |
| 3.2.    Mechanical Dimensions.....                  | 15        |
| <b>4. Connectors and Jumpers .....</b>              | <b>16</b> |
| 4.1.    Rear IO Connectors.....                     | 16        |
| 4.1.1.    DC Power Inlet.....                       | 16        |
| 4.1.2.    DisplayPort .....                         | 17        |
| 4.1.3.    HDMI Connector.....                       | 17        |
| 4.1.4.    Ethernet Connectors (LAN1, LAN2) .....    | 18        |
| 4.1.5.    USB 3.0 Connectors (USB1-4) .....         | 18        |
| 4.1.6.    Audio Connectors (Line-out, Mic-in) ..... | 19        |
| 4.2.    Internal Connectors .....                   | 19        |

|           |  |           |
|-----------|--|-----------|
| 4.2.1.    | ATX Power Connector 4-pin (ATX_PWR1) .....                     | 19        |
| 4.2.2.    | SATA Connectors (SATA1, SATA2, CN22-23) .....                  | 20        |
| 4.2.3.    | SATA Power Connector (ST_PWR, CN24) .....                      | 20        |
| 4.2.4.    | USB 2.0 Header (CN17).....                                     | 21        |
| 4.2.5.    | PS/2 Keyboard and Mouse Connector (CN19) .....                 | 22        |
| 4.2.6.    | Internal Audio Connector (CN16) .....                          | 22        |
| 4.2.7.    | CPU Fan and System Fan Connectors (CPU: CN36, SYS: CN37) ..... | 23        |
| 4.2.8.    | Serial COM Port Connectors (CN29-CN34).....                    | 23        |
| 4.2.9.    | LVDS Connector (CN13).....                                     | 25        |
| 4.2.10.   | LVDS Auxiliary Connector (CN14) .....                          | 26        |
| 4.2.11.   | Front Panel Connector (CN27).....                              | 27        |
| 4.2.12.   | Feature Connector (CN28).....                                  | 28        |
| 4.2.13.   | SPI Header (CN40) .....  | 29        |
| 4.2.14.   | DB40 Debug Board Connector.....                                | 30        |
| 4.3.      | Jumper and Switch Settings.....                                | 31        |
| 4.3.1.    | ATX/AT Mode Jumper Selection (JP1) .....                       | 31        |
| 4.3.2.    | Clear CMOS (JP6) .....   | 31        |
| 4.3.3.    | SATA1/mSATA Select (JP11) .....                                | 31        |
| 4.3.4.    | LVDS Backlight Power Jumper Selection (JP2).....               | 31        |
| 4.3.5.    | LVDS Panel Power Jumper Selection (JP3, JP5) .....             | 32        |
| 4.3.6.    | LVDS Backlight Enable Jumper Selection (JP4) .....             | 32        |
| 4.3.7.    | Serial Port Mode Switch Setting (SW4, SW5) .....               | 33        |
| 4.3.8.    | Serial Port Power Selection (JP7, JP8, JP9, JP10) .....        | 33        |
| 4.3.9.    | BIOS Switch Setting (BSW1).....                                | 34        |
| 4.4.      | Onboard Connector Information.....                             | 35        |
| <b>5.</b> | <b>Smart Embedded Management Agent (SEMA) .....</b>            | <b>36</b> |
| 5.1.      | Board Specific SEMA Functions .....                            | 36        |
| 5.1.1.    | Voltages .....   | 36        |
| 5.1.2.    | Main Current .....   | 37        |
| 5.1.3.    | BMC Status .....   | 37        |
| 5.1.4.    | Exception Codes .....  | 37        |
| 5.1.5.    | BMC Flags .....  | 38        |
| <b>6.</b> | <b>System Resources.....</b>                                   | <b>39</b> |
| 6.1.      | System Memory Map .....  | 39        |
| 6.2.      | I/O Map.....   | 39        |
| 6.2.1.    | I/O Map .....  | 39        |
| 6.2.2.    | IRQ Lines PIC mode.....  | 40        |
| 6.2.3.    | IRQ Lines APIC mode .....                                      | 41        |

|                            |  |           |
|----------------------------|--|-----------|
| 6.3.                       | PCI Configuration Space Map .....        | 42        |
| 6.4.                       | PCI Interrupt Routing Map.....           | 43        |
| 6.5.                       | SMBus Slave Address.....                 | 43        |
| <b>7.</b>                  | <b>BIOS Setup .....</b>                  | <b>44</b> |
| 7.1.                       | Menu Structure.....                      | 44        |
| 7.2.                       | Main.....                                | 45        |
| 7.2.1.                     | BIOS Information .....                   | 45        |
| 7.2.2.                     | System Information.....                  | 45        |
| 7.2.3.                     | Board Information .....                  | 46        |
| 7.2.4.                     | System Date and Time.....                | 46        |
| 7.3.                       | Advanced .....                           | 47        |
| 7.3.1.                     | CPU Configuration .....                  | 47        |
| 7.3.2.                     | Graphics Configuration.....              | 49        |
| 7.3.3.                     | Power Management.....                    | 50        |
| 7.3.4.                     | System Management.....                   | 51        |
| 7.3.5.                     | Thermal Management.....                  | 52        |
| 7.3.6.                     | Watchdog Timer .....                     | 53        |
| 7.3.7.                     | CSM Configuration.....                   | 54        |
| 7.3.8.                     | IT8783 Super IO Configuration .....      | 54        |
| 7.3.9.                     | Serial Console Redirection.....          | 55        |
| 7.3.10.                    | USB .....                                | 57        |
| 7.3.11.                    | Network.....                             | 57        |
| 7.3.12.                    | Miscellaneous.....                       | 57        |
| 7.3.13.                    | Trusted Computing.....                   | 57        |
| 7.3.14.                    | AMI Graphic Output Protocol Policy ..... | 58        |
| 7.3.15.                    | SDIO Configuration .....                 | 58        |
| 7.4.                       | Chipset .....                            | 59        |
| 7.4.1.                     | North Bridge .....                       | 59        |
| 7.4.2.                     | South Bridge .....                       | 59        |
| 7.4.3.                     | Uncore Configuration .....               | 60        |
| 7.4.4.                     | South Cluster Configuration .....        | 61        |
| 7.5.                       | Security .....                           | 66        |
| 7.5.1.                     | Password Description .....               | 66        |
| 7.6.                       | Boot .....                               | 66        |
| 7.6.1.                     | Boot Configuration .....                 | 66        |
| <b>Safety Instructions</b> | <b>.....</b>                             | <b>67</b> |
| <b>Getting Service</b>     | <b>.....</b>                             | <b>68</b> |

## 1. Introduction

The AmITX-AL-I is a low-profile Thin Mini-ITX embedded board supporting an Intel® Atom™ processor E3900 series, Intel® Pentium® processor N4200, and Intel® Celeron® processor N3350 system-on-chip (SoC). The AmITX-AL-I is specifically designed for customers who need optimized processing and graphics performance with low power consumption in a long product life solution.

The Intel® Atom™ processor, Intel® Pentium® processor, and Intel® Celeron® processor support non-ECC type DDR3L dual-channel memory at 1600/1867 MHz to provide excellent overall performance. Integrated Intel® Gen9 LP Graphics includes features such as OpenGL 4.3, DirectX 12, OpenCL 2.0; and support for H.265/HEVC, H.264, MPEG2, VC1, VP9, MVC, JPEG/MJPEG hardware decode. Up to three independent displays are available from DDI ports supporting HDMI/DisplayPort, optional single/dual-channel 18/24-bit LVDS, and optional eDP.

The AmITX-AL-I supports dual stacked SODIMM sockets for up to 16 GB non-ECC type DDR3L memory, and graphics outputs include DisplayPort, HDMI, and optional eDP and optional dual-channel 18/24-bit LVDS. I/O features include HD Audio, dual Gigabit Ethernet port, 4x USB 3.0 ports and 3x USB 2.0 ports, 6x COM ports, PCIe x1 slot, Mini PCIe slot, mSATA slot, and 2x SATA 6 Gb/s ports. A feature connector provides 10 GPIO, SMBus, and I²C, and optional SIM card slot and microSD card slot are available. The AmITX-AL-I is equipped with SPI AMI BIOS, supporting embedded features such as hardware monitor and watchdog timer.

The Thin Mini-ITX form factor is the “premier standard for designing and assembling all-in-one PCs,” according to Intel. Measuring 170 mm square and less than 25 mm thick, Thin Mini-ITX fulfills requirements for applications in digital signage, infotainment, medical, and industrial automation that are running in limited-space environments. ADLINK’s thin Mini-ITX board also follows the Form, Fit, Function design principle to offer standardized pinout locations and is compatible with the Micro-ATX and regular ATX chassis. The AmITX-AL-I provides an easy and fast path to creating industrial computing solutions.

| Model            | Intel “Braswell” SoC     | Core Speed (HFM/Burst) | Thermal Design Power (TDP) | Scenario Design Power (SDP) |
|------------------|--------------------------|------------------------|----------------------------|-----------------------------|
| AmITX-AL-I-E3950 | Atom™ x7-E3950 (4 cores) | 1.60/2.00 GHz          | 12W                        |                             |
| AmITX-AL-I-E3940 | Atom™ x5-E3940 (4 cores) | 1.60/1.80 GHz          | 9.5W                       |                             |
| AmITX-AL-I-E3930 | Atom™ x5-E3930 (2 cores) | 1.30/1.80 GHz          | 6.5W                       |                             |
| AmITX-AL-I-N4200 | Pentium® N4200 (4 cores) | 1.10/2.50 GHz          | 6W                         | 4W                          |
| AmITX-AL-I-N3350 | Celeron® N3350 (2 cores) | 1.10/2.40 GHz          | 6W                         | 4W                          |

Latest revision of the datasheet, user's manual, BIOS, drivers, and board support packages, can be downloaded from the product webpage:  
[http://www.adlinktech.com/PD/web/PD\\_detail.php?cKind=&pid=1667#](http://www.adlinktech.com/PD/web/PD_detail.php?cKind=&pid=1667#)

## 1.1. Packing List

- AmITX-AL-I Thin Mini-ITX Embedded Board
- SATA dual power cable (P/N: 30-20875-0000)
- SATA cable (P/N: 30-10057-0600)
- Standard rear I/O shield (P/N: TBD)

## 1.2. Optional Accessories

- COM port cable, 1 port (P/N: 30-20876-0000)
- PS/2 KB/MS cable (P/N: 30-20873-0000)
- USB 2.0 cable, 2 ports (P/N: 30-20874-1000)
- Low profile rear I/O shield (P/N: TBD)

## 2. Specifications

### 2.1. Core System

- CPU: Dual or quad-core Intel® Atom™, Pentium®, and Celeron® Processor SoC
  - Atom™ x7-E3950 1.60/2.00 (Burst) GHz 12W (4C/1866)
  - Atom™ x7-E3940 1.60/1.80 (Burst) GHz 9.5W (4C/1866)
  - Atom™ x5-E3930 1.30/1.80 (Burst) GHz 6.5W (2C/1866)
  - Pentium® N4200 1.10/2.50 (Burst) GHz 6W (4W SDP) (4C/1866)
  - Celeron® N3350 1.10/2.40 (Burst) GHz, 6W (4W SDP) (2C/1866)

Supports: Dual or quad Out-of-Order Execution (OOE) processor cores, Intel® VT-x, Intel® VT-d, Intel® SSE4.1 and SSE4.2, Intel® 64 architecture, Intel® Turbo Boost Technology 2.0, Intel AES-NI, Intel® TXT, PCLMULQDQ instruction DRNG

Note: Availability of features may vary between processor SKUs and operating systems.

Note: Only Atom™ SKUs can support extreme temperature operating range.

- Cache: 2MB for all SKUs
- Memory: Dual channel non-ECC 1600/1333 MHz DDR3L memory up to 8GB in dual stacked SODIMM sockets
- Embedded BIOS: AMI EFI in 8MB SPI BIOS

### 2.2. Rear I/O Connectors

- Display: 1x DisportPort (2x DisplayPort by build option, in place of HDMI), 1x HDMI (co-lay with DP)
- LAN: Dual GbE RJ-45
- USB: 4x USB 3.0
- Aduio: Line-Out, Mic-In
- Power: Screw Jack for 12V DC-in

### 2.3. Internal Headers and Connectors

- PCIe x1 slot
- 2x Mini PCIe slots: one PCIe + USB; one mSATA
- USB: 2x USB 2.0 via onboard header, 1x USB 2.0 via front panel connector
- SATA: 2x SATA 6Gb/s (SATA0, SATA1)
- SATA Power Connector
- Serial: 2x RS-232/422/485 headers with 0V/5V/12V power, 4x RS-232 headers
- LVDS (optional): dual-channel 18/24-bit, switched from eDP (build option)
- eDP (optional): build option, not available concurrently with LVDS
- SIM Card slot (build option)
- microSD Card slot (build option)
- Front Panel Header
- Audio Header
- Feature Connector Header
- PS/2 KB/MS Connector
- TPM Header
- SPI Header
- ATX Power Connector (4-pin)

## 2.4. Form Factor

- Mini-ITX: 170mm x 170mm

## 2.5. SEMA Board Controller

- ADLINK Smart Embedded Management Agent (SEMA)

- Voltage/Current monitoring
- Power sequence debug support
- AT/ATX mode control
- Logistics and Forensic information
- Flat Panel Control
- General Purpose I2C
- Failsafe BIOS (dual BIOS )
- Watchdog Timer and Fan Control

## 2.6. Debug Header

- 40-pin Multipurpose Flat Cable Connector:, used in combination with DB-40 debug module providing BIOS POST code LED, BMC access, SPI BIOS flashing, Power Testpoints, Debug LEDs

## 2.7. Video

- GPU Feature Support: Intel® 9th generation LP graphics core architecture with up to 18 execution units supporting three independent displays

- 3D graphics hardware acceleration
- Support for DirectX12/11.3/10/9.3, OCL 2.0, OGL ES 3.0, OGL 4.3
- Video decode hardware acceleration including support for H.265 (HEVC), H.264, MVC, MPEG-2, VC-1, WMV9, VP8/VP9, JPEG/MJPEG formats
- Video encode hardware acceleration including support for H.265 (HEVC), H.264, VP8/VP9, JPEG/MJPEG formats
- Supports content protection using PAVP 2.0 and HDCP 1.4/2.0

Note: Availability of features dependent on processor SKU and may vary between operating systems.

- Display Interface Support

- DisplayPort: Supports DP1.2, maximum resolution: 4096x2160 @ 60Hz (2x DisplayPort by build option, in place of HDMI)
- HDMI: Supports HDMI 1.4b, maximum resolution: 3840x2160 @ 30Hz (co-lay with DP)
- LVDS (optional): Supports single/dual channel 18/24-bit, up to 1920x1200 @ 60 Hz
- eDP (optional): Supports eDP 1.3, maximum resolution: 3840x2160 @ 60Hz

Note: The configuration of triple display support is DP + HDMI + LVDS/eDP (2x DP + LVDS/eDP by build option)

## 2.8. Audio

- Audio Codec: ALC888S

## 2.9. LAN

- Intel MAC/PHY: Intel® i211AT (MAC/PHY) Ethernet Controller (Intel® i210 by build option for extreme operating temperature range support)
- Interface: 10/100/1000 GbE connection

## 2.10. Power Specification

- Power Modes: AT and ATX mode (AT mode start controlled by BMC)
- Standard Voltage Input: 12VDC ±5%
- Power Management: ACPI 4.0 compliant
- Power States: Supports C0, C1, C1E, C6C, C6, C7, S0, S1, S3, S4, S5 (Wake-on-USB S3/S4, WoL S3/S4/S5)

## 2.11. Temperatures

- Standard Operating Temperature: 0°C to 60°C
- Extreme Rugged Operating Temperature: -40°C to 85°C (build option, supported by Atom™ SKUs only)


## 2.12. Environmental

- Humidity: 10-90% RH operating, non-condensing  
5-95% RH storage (and operating with conformal coating)
- Shock and Vibration: IEC 60068-2-64 and IEC-60068-2-27  
MIL-STD-202F, Method 213B, Table 213-I, Condition A and Method 214A, Table 214-I, Condition D
- HALT: Thermal Stress, Vibration Stress, Thermal Shock and Combined Test

## 2.13. Operating Systems

- Standard Support: Windows 10 Enterprise 64-bit, Linux 64-bit, (VxWorks 64-bit is TBD)
- Extended Support (BSP): Linux 64-bit, (VxWorks 64-bit is TBD)


## 2.14. Functional Diagram




### 3. Mechanical Layout

#### 3.1. Connector Locations


##### 3.1.1. Rear I/O




##### 3.1.2. Top Side Connectors



### 3.1.3. Bottom Side Connectors



### 3.2. Mechanical Dimensions



## 4. Connectors and Jumpers


See 3.1 Connector Locations on page 13 for connector locations.

### 4.1. Rear IO Connectors

#### 4.1.1. DC Power Inlet

The AmlTX-AL-I supports a screw-type external 12V DC-in power connector. Maximum current draw is 10A.

Note: Either the DC Power Inlet or the internal ATX Power Connector (ATX\_PWR) must be used to supply the motherboard with +12V  $\pm 5\%$ .



**Caution:**


Hot-plugging the power supply is not supported. Doing so may damage the board.

Only connect ONE power supply to the board. Connecting power to both the 12V DC-inlet and the internal ATX Power Connector may damage the board.

#### 4.1.2. DisplayPort

DisplayPort v1.2 specification ports up to 4096x2160 @ 60Hz (2x DisplayPort by build option, in place of HDMI)


| Pin # | Signal   | Pin # | Signal   |
|-------|----------|-------|----------|
| 1     | CN_DP0_P | 2     | Ground   |
| 3     | CN_DP0_N | 4     | CN_DP1_P |
| 5     | Ground   | 6     | CN_DP1_N |
| 7     | CN_DP2_P | 8     | Ground   |
| 9     | CN_DP2_N | 10    | CN_DP3_P |
| 11    | Ground   | 12    | CN_DP3_N |
| 13    | CN_CAD-L | 14    | CN_CEC   |
| 15    | CN_AUX_P | 16    | Ground   |
| 17    | CN_AUX_N | 18    | DDP_HPD  |
| 19    | Ground   | 20    | P3V3     |



#### 4.1.3. HDMI Connector

Supports HDMI 1.4b, maximum resolution: 3840x2160 @ 30Hz (co-lay with DP)


| Pin # | Signal            | Pin # | Signal            |
|-------|-------------------|-------|-------------------|
| 1     | TMDS Data2+       | 2     | TMDS Data2 Shield |
| 3     | TMDS Data2-       | 4     | TMDS Data1+       |
| 5     | TMDS Data1 Shield | 6     | TMDS Data1-       |
| 7     | TMDS Data0+       | 8     | TMDS Data0 Shield |
| 9     | TMDS Data0-       | 10    | TMDS Clock+       |
| 11    | TMDS Clock Shield | 12    | TMDS Clock-       |
| 13    | CEC               | 14    | Reserved          |
| 15    | SCL               | 16    | SDA               |
| 17    | DDC/CEC Ground    | 18    | +5 V Power        |
| 19    | Hot Plug Detect   |       |                   |



#### 4.1.4. Ethernet Connectors (LAN1, LAN2)

Intel® i211AT (MAC/PHY) Ethernet controller (Intel® i210 is build option for extreme temperature operating range support)


| Pin # | 10BASE-T/100BASE-TX | 1000BASE-T |
|-------|---------------------|------------|
| 1     | TX+                 | LAN_MDI0+  |
| 2     | TX-                 | LAN_MDI0-  |
| 3     | RX+                 | LAN_MDI1+  |
| 4     | --                  | LAN_MDI2+  |
| 5     | --                  | LAN_MDI2-  |
| 6     | RX-                 | LAN_MDI1-  |
| 7     | --                  | LAN_MDI3+  |
| 8     | --                  | LAN_MDI3-  |



| LED1 (Speed) |                   | LED2 (Link/Activity) |               |
|--------------|-------------------|----------------------|---------------|
| Status       | Description       | Status               | Description   |
| Off          | 10 Mb connection  | Off                  | No Link       |
| Green        | 100 Mb connection | Orange               | Linked        |
| Orange       | 1 Gb connection   | Blinking             | Data Activity |

#### 4.1.5. USB 3.0 Connectors (USB1-4)

| Pin # | Signal      |
|-------|-------------|
| 1     | USB3.0_P5VA |
| 2     | USB2_CMAN   |
| 3     | USB2_CMAP   |
| 4     | GND         |
| 5     | USB3A_CMRXN |
| 6     | USB3A_CMRXP |
| 7     | GND         |
| 8     | USB3A_CMTXN |
| 9     | USB3A_CMTXP |



#### 4.1.6. Audio Connectors (Line-out, Mic-in)

Audio Codec: Realtek ALC888S

| Jack     | Contact | Signal      |
|----------|---------|-------------|
| Line-out | Tip     | FRONT-OUT-L |
|          | Ring    | FRONT-OUT-R |
|          | Sleeve  | GND         |
| Mic-in   | Tip     | MIC1-L      |
|          | Ring    | MIC1-R      |
|          | Sleeve  | GND         |

Note: Shared with onboard Audio Header; un-amplified codec output.


## 4.2. Internal Connectors

### 4.2.1. ATX Power Connector 4-pin (ATX\_PWR1)

AmITX-AL-I supports a proprietary internal ATX Power Connector (4-pin).

Note: Either the DC Power Inlet or the internal ATX Power Connector (4-pin) must be used to supply the motherboard with +12V ±5%.

| Pin # | Signal  |
|-------|---------|
| 1     | GND     |
| 2     | GND     |
| 3     | +12V DC |
| 4     | +12V DC |



Only connect ONE power supply to the board. Connecting power to both the 12V DC-inlet and the internal ATX Power Connector may damage the board.

#### 4.2.2. SATA Connectors (SATA1, SATA2, CN22-23)

Two SATA ports are available on the AmlTX-AL-I and support SATA Gen3 (6.0/3.0/1.5Gb/s).


Note: If mSATA is installed, SATA1 is disabled. See 4.3.3 SATA1/mSATA Select (JP11).

| Pin # | Signal |
|-------|--------|
| 1     | GND    |
| 2     | TXP    |
| 3     | TXN    |
| 4     | GND    |
| 5     | RXN    |
| 6     | RXP    |
| 7     | GND    |




#### 4.2.3. SATA Power Connector (ST\_PWR, CN24)

| Pin # | Signal |
|-------|--------|
| 1     | 12V    |
| 2     | GND    |
| 3     | 5V     |
| 4     | GND    |
| 5     | 3.3V   |




SATA Power Cable: ADLINK Part. No.: 30-20875-0000 (length 200 mm)




#### 4.2.4. USB 2.0 Header (CN17)

5V/SB5V: 5V supplies for external devices. SB5V is supplied during power down to allow wakeup on USB device activity during S3~S4 state.




| Pin # | Signal   | Pin # | Signal  |
|-------|----------|-------|---------|
| 1     | P5V_USB  | 2     | P5V_USB |
| 3     | P2_DN_R- | 4     | P3_DN_R |
| 5     | P2_DP_R  | 6     | P3_DP_R |
| 7     | GND      | 8     | GND     |
| 9     | KEY      | 10    | GND     |



#### USB Cable (optional):


USB 2.0 Header to 2x Female Type-A Cable (length 200mm), P/N: 30-20874-1000



#### 4.2.5. PS/2 Keyboard and Mouse Connector (CN19)


6 pin 2.0 pitch standard wafer connector. No support for PS/2 KB/MS wake function

| Pin # | Signal |
|-------|--------|
| 1     | MSCLK  |
| 2     | V5S_S3 |
| 3     | MSDATA |
| 4     | GND    |
| 5     | KBDATA |
| 6     | KBCLK  |



KB/MS Cable (optional):

PS/2 KB/MS Cable (length 400mm), P/N: 30-20873-0000




#### 4.2.6. Internal Audio Connector (CN16)

2x16-pin 2.0 pitch standard wafer connector.

Note: Signals shared with Audio Connector on Rear I/O.

| Signal     | Pin # | Pin # | Signal      |
|------------|-------|-------|-------------|
| LFE_R      | 1     | 2     | CEN_L       |
| AGND_AU    | 3     | 4     | AGND_AU     |
| LOUT_L_CN  | 5     | 6     | LOUT_R_CN   |
| AGND_AU    | 7     | 8     | AGND_AU     |
| SURR_LO    | 9     | 10    | SURR_RO     |
| SIDE_L     | 11    | 12    | SIDE_R      |
| AGND_AU    | 13    | 14    | AGND_AU     |
| MICIN_L_CN | 15    | 16    | MICIN_R_CN  |
| AGND_AU    | 17    | 18    | AGND_AU     |
| LIN_L      | 19    | 20    | LIN_R       |
| MUTE       | 21    | 22    | AGND_AU     |
| GND        | 23    | 24    | NC          |
| SPDO       | 25    | 26    | GND         |
| LINE1_JD   | 27    | 28    | CEN_JD      |
| SURR_JD    | 29    | 30    | FRONT_JD    |
| MIC1_JD    | 31    | 32    | SIDESURR_JD |



BH\_32\_S2.0mn

#### 4.2.7. CPU Fan and System Fan Connectors (CPU: CN36, SYS: CN37)

Pin 3 and 4 are connected (monitored and managed) by SEMA controller.


| Pin # | Signal            |
|-------|-------------------|
| 1     | GND               |
| 2     | Fan Power (+12V)  |
| 3     | Fan Sense         |
| 4     | Fan Speed Control |



#### 4.2.8. Serial COM Port Connectors (CN29-CN34)

Four internal Serial Ports (COM1-6)

| Serial Port | Functions  |
|-------------|--|
| COM1        | Supports RS-232/422/485, 0V/5V/12V power support by jumper selection<br>SW4: Switch for mode selection of COM1 (default RS-232). |
| COM2        | Supports RS-232/422/485, 0V/5V/12V power support by jumper selection<br>SW5: Switch for mode selection of COM2 (default RS-232). |
| COM3        | Supports RS-232  |
| COM4        | Supports RS-232  |
| COM5        | Supports RS-232  |
| COM6        | Supports RS-232  |



##### RS-232 (COM1-6)

| Pin # | Signal | Pin # | Signal   |
|-------|--------|-------|----------|
| 1     | DCD    | 2     | DSR      |
| 3     | RxD    | 4     | RTS      |
| 5     | TxD    | 6     | CTS      |
| 7     | DTR    | 8     | RI       |
| 9     | GND    | 10    | 5V / 12V |

##### RS-422 (COM1-2 only)

| Pin # | Signal | Pin # | Signal   |
|-------|--------|-------|----------|
| 1     | Tx-    | 2     | —        |
| 3     | Tx+    | 4     | —        |
| 5     | Rx+    | 6     | —        |
| 7     | Rx-    | 8     | —        |
| 9     | GND    | 10    | 5V / 12V |

## RS-485 (COM1-2 only)

| Pin # | Signal | Pin # | Signal   |
|-------|--------|-------|----------|
| 1     | Tx/Rx- | 2     | —        |
| 3     | Tx/Rx+ | 4     | —        |
| 5     | —      | 6     | —        |
| 7     | —      | 8     | —        |
| 9     | GND    | 10    | 5V / 12V |

## RS-232/422/485 Selection (COM1-2 only)

| SW4/SW5 (RS-232/422/485 Mode Select) |                  |        |        |
|--------------------------------------|------------------|--------|--------|
|                                      | RS-232 (default) | RS-422 | RS-485 |
| 1                                    | ON*              | ON     | OFF    |
| 2                                    | OFF*             | ON     | ON     |

## COM1 Power selection (JP7, JP8)

| JP7 COM1 PWR |      |
|--------------|------|
| 1-2          | +12V |
| 3-4          | +5V  |

| JP8 COM1 PWR |              |
|--------------|--------------|
| 1-2          | GND          |
| 3-4          | RI (default) |

## COM2 Power selection (JP9, JP10)

| JP9 COM2 PWR |      |
|--------------|------|
| 1-2          | +12V |
| 3-4          | +5V  |

| JP10 COM2 PWR |              |
|---------------|--------------|
| 1-2           | GND          |
| 3-4           | RI (default) |

## COM Cable (optional):

COM Port Cable (length 250mm), P/N: 30-20876-0000



## 4.2.9. LVDS Connector (CN13)

FFC Connector: Female, 30pin, 1mm pitch. (JAE, FI-X30SSLA-HF)

Supports non-EDID type LCD panels.

| Signal      | Description   |
|-------------|---|
| LVDS A0..A3 | LVDS A Channel data   |
| LVDS ACLK   | LVDS A Channel clock  |
| LVDS B0..B3 | LVDS B Channel data   |
| LVDS BCLK   | LVDS B Channel clock  |
| VDD ENABLE  | Output Display Enable.  |
| LCDVCC      | VCC supply to the display. Power-on/off sequencing depending on selected display type in the BIOS Setup.<br>Switchable by jumper either 3.3V (default) or 5V. Maximum load is 1A total for both voltages. |
| DDC CLK     | DDC Channel Clock   |
| DDC DAT     | DDC Channel Data  |

| Note      | Type | Signal     | Pin # | Pin # | Signal     | Type | Note          |
|-----------|------|------------|-------|-------|------------|------|---------------|
|           | LVDS | LVDS A0-   | 1     | 16    | LVDS B1+   | LVDS |               |
|           | LVDS | LVDS A0+   | 2     | 17    | POWER GND  | PWR  | Max. 0.5A     |
|           | LVDS | LVDS A1-   | 3     | 18    | LVDS B2-   | LVDS |               |
|           | LVDS | LVDS A1+   | 4     | 19    | LVDS B2+   | LVDS |               |
|           | LVDS | LVDS A2-   | 5     | 20    | LVDS BCLK- | LVDS |               |
|           | LVDS | LVDS A2+   | 6     | 21    | LVDS BCLK+ | LVDS |               |
| Max. 0.5A | PWR  | POWER GND  | 7     | 22    | LVDS B3-   | LVDS |               |
|           | LVDS | LVDS ACLK- | 8     | 23    | LVDS B3+   | LVDS |               |
|           | LVDS | LVDS ACLK+ | 9     | 24    | POWER GND  | PWR  | Max. 0.5A     |
|           | LVDS | LVDS A3-   | 10    | 25    | DDC DATA   | OT   | PU 2K2Ω, 3.3V |
|           | LVDS | LVDS A3+   | 11    | 26    | VDD ENABLE | OT   | 3.3V level    |
|           | LVDS | LVDS B0-   | 12    | 27    | DDC CLK    | OT   | PU 2K2Ω, 3.3V |
|           | LVDS | LVDS B0+   | 13    | 28    | LCDVCC     | PWR  | Max 0.5A      |
| Max. 0.5A | PWR  | POWER GND  | 14    | 29    | LCDVCC     | PWR  | Max 0.5A      |
|           | LVDS | LVDS B1-   | 15    | 30    | LCDVCC     | PWR  | Max 0.5A      |

#### 4.2.10. LVDS Auxiliary Connector (CN14)

Wafer 1x10 pin: 1.25 mm pitch (MOLEX, 53261-1071)

| Pin | Type | Signal   | Note       |
|-----|------|----------|------------|
| 1   | OT   | BKLT_EN# | 3.3V level |
| 2   | PWR  | GND      | Max. 0.5A  |
| 3   | PWR  | GND      | Max. 0.5A  |
| 4   | PWR  | BKLT_PWR | Max. 0.5A  |
| 5   | PWR  | BKLT_PWR | Max. 0.5A  |
| 6   | PWR  | BKLT_PWR | Max. 0.5A  |
| 7   | PWR  | BKLT_PWR | Max. 0.5A  |
| 8   | PWR  | GND      | Max. 0.5A  |
| 9   | PWR  | GND      | Max. 0.5A  |
| 10  | OT   | BKLT_CTL | 3.3V level |

| Signal   | Description   |
|----------|---|
| BKLT_EN# | Backlight Enable signal (active low)<br>Optional to invert this signal to active high BKLT_EN (by jumper) |
| BKLT_PWR | Backlight Power switchable by jumper either 5V (default) or 12V. Maximum 1A per pin for both voltages     |
| BKLT_CTL | Backlight control, PWM signal to implement voltage in the range 0-3.3V                                    |


See Section 4.3 Jumper and Switch Settings for Backlight Power Selection (JP2), Backlight Enable Selection (JP4), and Panel Power Selection (JP3, JP5) settings.

#### 4.2.11. Front Panel Connector (CN27)

2x12-pin 2.0 pitch standard wafer connector

The front panel connector of AmITX-AL-I provides one USB2.0 header, Audio MIC-In / Line-Out, ATX power switch, Reset, HDD LED, and SUS LED (System Power LED).

| Pin # | Signal    | Ioh/ Iol | Type | Note | Pin # | Signal     | Type | Ioh/ Iol | Note |
|-------|-----------|----------|------|------|-------|------------|------|----------|------|
| 1     | USB7_5V   | -        | PWR  |      | 2     | USB7_5V    | PWR  | -        |      |
| 3     | USB7-     | -        | S    |      | 4     | MIC2_JD    | S    | -        |      |
| 5     | USB7+     | -        | S    |      | 6     | LINE2_JD   | S    | -        |      |
| 7     | GND       | -        | PWR  |      | 8     | GND        | PWR  | -        |      |
| 9     | NC        | -        | NC   |      | 10    | LINE2-L    | S    | -        |      |
| 11    | +5V       | -        | PWR  |      | 12    | +5V        | PWR  | -        |      |
| 13    | SATA_LED# |          | O    |      | 14    | SUS_LED    | O    |          | 1    |
| 15    | GND       | -        | PWR  |      | 16    | PWRBTN_IN# | I    |          |      |
| 17    | RSTIN#    | -        | I    |      | 18    | GND        | PWR  | -        |      |
| 19    | SB3V3     | -        | PWR  |      | 20    | LINE2-R    | S    | -        |      |
| 21    | AGND      | -        | PWR  |      | 22    | AGND       | PWR  | -        |      |
| 23    | MIC2-R    | -        | S    |      | 24    | MIC2-R     | S    | -        |      |



Note 1: Connect SUS\_LED (System Power LED) to the power status indicator on the chassis front panel. The LED is on when the system is operating. The LED keeps blinking when the system is in S1/S3 sleep state. The LED is off when the system is in S4 sleep state or powered off (S5).

Pin 2.54 pitch standard connector (CN6401-CN6404)

| CN6401 |            |      |
|--------|------------|------|
| Pin #  | Signal     | Type |
| 1      | PWRBTN_IN# | I    |
| 2      | GND        | PWR  |

| CN6402 |        |      |
|--------|--------|------|
| Pin #  | Signal | Type |
| 1      | RSTIN# | I    |
| 2      | GND    | PWR  |

| CN6403 |           |      |           |
|--------|-----------|------|-----------|
| Pin #  | Signal    | Type | PU/D      |
| 1      | +3V       | PWR  | PU 3300HM |
| 2      | SATA_LED# | O    |           |

| CN6404 |         |      |           |
|--------|---------|------|-----------|
| Pin #  | Signal  | Type | PU/D      |
| 1      | SB3V3   | PWR  | PU 3300HM |
| 2      | SUS_LED | O    |           |

#### 4.2.12. Feature Connector (CN28)

2x14-pin 2.0 pitch standard wafer connector


The feature connector of AmITX-AL-I provides Case Open, I2C, SMBus, and GPIO (10pin).

| Signal      | Description   |
|-------------|---|
| TEMPS       | Analogue temp sensor, connect to analog input of BMC  |
| EXT_BAT     | Connect to RTC power  |
| CASE_OPEN#  | Any time case open occurred, system will notice/show case open alert in POST when the next booting. |
| I2CC / I2CD | Connect to BMC (I2C Master)   |
| I2C         | SEMA  |

| Pin # | Signal     | Pull U/D | Ioh/ Iol | Type | Note | Pin # | Signal  | Type | Ioh/ Iol | Pull U/D | Note |
|-------|------------|----------|----------|------|------|-------|---------|------|----------|----------|------|
| 1     | CASE_OPEN# | PU 2M    | -        | I    |      | 2     | SMBC    | OT   | /4mA     | PU 10K   | 1    |
| 3     | GND        | -        | -        | PWR  |      | 4     | SMBD    | OT   | /4mA     | PU 10K   | 1    |
| 5     | TEMPS      | -        |          | I    | 2    | 6     | I2CC    | OT   | -        | PU 10K   | 1    |
| 7     | EXT_BAT    | -        |          | PWR  |      | 8     | I2CD    | OT   | -        | PU 10K   | 1    |
| 9     | SB3V3      | -        | -        | PWR  |      | 10    | SB5V    | PWR  | -        | -        |      |
| 11    | GND        | -        | -        | PWR  |      | 12    | GND     | PWR  | -        | -        |      |
| 13    | GPIO0      | -        | PU10K3V3 | IOT  |      | 14    | GPIO1   | IOT  |          | PU10K3V3 |      |
| 15    | GPIO2      | -        | PU10K3V3 | IOT  |      | 16    | GPIO3   | IOT  |          | PU10K3V3 |      |
| 17    | GPIO4      | -        | PU10K3V3 | IOT  |      | 18    | GPIO5   | IOT  |          | PU10K3V3 |      |
| 19    | GPIO6      | -        | PU10K3V3 | IOT  |      | 20    | GPIO7   | IOT  |          | PU10K3V3 |      |
| 21    | GPIO8      |          | PU10K3V3 | IOT  |      | 22    | GPIO9   | IOT  |          | PU10K3V3 |      |
| 23    | GND        | -        |          | PWR  |      | 24    | SUS_S3# | O    | 25/25mA  | -        |      |
| 25    | 12V        | -        | -        | PWR  |      | 26    | SUS_S4# | O    | 25/25mA  | -        |      |
| 27    | PWR_OK     | -        | 25/25mA  | O    |      | 28    | SUS_S5# | O    | 25/25mA  | -        |      |

Note 1: Pull-up to +3V3Dual (+3V3 or SB3V3).


Note 2: Input to SEMA.



#### 4.2.13. SPI Header (CN40)

2x6-pin 2.0 pitch standard wafer connector


| Type | Signal      | Pin # | Pin # | Signal        | Type |
|------|-------------|-------|-------|---------------|------|
|      | CLK         | 1     | 2     | SB3V3         | PWR  |
| I    | CS0#        | 3     | 4     | ADDIN         | IO   |
| I    | CS1#        | 5     | 6     | NC            | -    |
| I    | MOSI        | 7     | 8     | ISOLATE       | IO   |
| O    | MISO        | 9     | 10    | GND           | PWR  |
| IO   | SPI_IO2_#WP | 11    | 12    | SPI_IO3_#HOLD | IO   |



| Signal        | Description  |
|---------------|--|
| CLK           | Serial Clock   |
| SB3V3         | 3.3V Standby Voltage power line. Normally output power, but when Motherboard is turned off then the on-board SPI Flash can be 3.3V power sourced via this pin.   |
| CS0#          | CS0# Chip Select 0, active low.  |
| ADDIN         | ADDIN input signal must be NC.   |
| MOSI          | Master Output, Slave Input   |
| ISOLATE#      | The ISOLATE# input, active low, is normally NC, but must be connected to GND when loading SPI flash. Power Supply to the Motherboard must be turned off when loading SPI flash. The pull up resistor is connected via diode to 5VSB. |
| MISO          | Master Input, Slave Output   |
| SPI_IO2_#WP   | SPI Data I/O: A bidirectional signal used to support the new Dual IO Fast Read, Quad IO Fast Read and Quad Output Fast Read modes. This signal is not used in Dual Output Fast Read mode.  |
| SPI_IO3_#HOLD | SPI Data I/O: A bidirectional signal used to support the new Dual IO Fast Read, Quad IO Fast Read and Quad Output Fast Read modes. This signal is not used in Dual Output Fast Read mode.  |

#### 4.2.14. DB40 Debug Board Connector

FPC Connector Type: FCI 59GF Flex 10042867



1

40

| Pin | Interface             | Signal        | Remark   | Pin | Interface                         | Signal       | Remark  |
|-----|-----------------------|---------------|--|-----|-----------------------------------|--------------|---|
| 1   | SPI Program interface | VCC_SPI_IN    | SPI Power Input from flash tool to module. HW need add MOS FET to switch SPI power for SPI ROM | 21  | BMC Program interface (continued) | TXD6         |   |
| 2   |                       | GND           |  | 22  |                                   | RXD6         |   |
| 3   |                       | SPI_BIOS_CS0# |  | 23  |                                   | FUMDO        |   |
| 4   |                       | SPI_BIOS_CS1# |  | 24  |                                   | RESET_IN#    |   |
| 5   |                       | SPI_BIOS_MISO |  | 25  |                                   | DATA         |   |
| 6   |                       | SPI_BIOS_MOSI |  | 26  |                                   | CLK          |   |
| 7   |                       | SPI_BIOS_CLK  |  | 27  |                                   | OCD0A        | Include a jumper to connect OCD0A via 1K0 pull-up to 3.3V_BMC |
| 8   | LPC Bus               | 3V3_LPC       | System power 3.3V provide from COM module  | 28  | Test points                       | OCD0B        | Include a jumper to connect OCD0B via 1K0 pull-up to 3.3V_BMC |
| 9   |                       | GND           |  | 29  |                                   | PWRBTN#      |   |
| 10  |                       | CB_RESET#     | Platform Reset   | 30  |                                   | SYS_RESET#   |   |
| 11  |                       | RST#          |  | 31  |                                   | CB_RESET#    |   |
| 12  |                       | CLK33_LPC     |  | 32  |                                   | CB_PWROK     |   |
| 13  |                       | LPC_FRAME#    |  | 33  |                                   | SUS_S3#      |   |
| 14  |                       | LPC_AD3       |  | 34  |                                   | SUS_S4#      |   |
| 15  |                       | LPC_AD2       |  | 35  |                                   | SUS_S5#      |   |
| 16  |                       | LPC_AD1       | always power 3.3V provide from COM module  | 36  | BMC Debug signals                 | POSTWDT_DIS# | Connect to Jumper for Debug                                   |
| 17  |                       | LPC_AD0       |  | 37  |                                   | SEL BIOS     | Connect to Jumper for Debug                                   |
| 18  | BMC Program interface | 3.3V_BMC      | always power 3.3V provide from COM module  | 38  |                                   | BIOS_MODE    | Connect to Jumper for Debug                                   |
| 19  |                       | 3.3V_BMC      | always power 3.3V provide from COM module  | 39  |                                   | BMC_STATUS   |   |
| 20  |                       | GND           |  | 40  | Reserved                          |              |   |

Note: the pin description on the Debug Module is the inverse of that on the motherboard.

### 4.3. Jumper and Switch Settings

#### 4.3.1. ATX/AT Mode Jumper Selection (JP1)

| JP1 | ATX/AT Mode   |
|-----|---------------|
| 1-2 | ATX (default) |
| 2-3 | AT            |

#### 4.3.2. Clear CMOS (JP6)

| JP6 | Clear CMOS       |
|-----|------------------|
| 1-2 | Normal (default) |
| 2-3 | Clear CMOS       |

#### 4.3.3. SATA1/mSATA Select (JP11)

| JP1 | SATA1/mSATA Select |
|-----|--------------------|
| 1-2 | SATA2 (default)    |
| 2-3 | mSATA              |


#### 4.3.4. LVDS Backlight Power Jumper Selection (JP2)

| JP2 | Backlight Power |
|-----|-----------------|
| 1-2 | 12V             |
| 2-3 | 5V (default)    |

#### 4.3.5. LVDS Panel Power Jumper Selection (JP3, JP5)

| JP3/JP5 | Panel Power    |
|---------|----------------|
| 1-2     | 5V             |
| 2-3*    | 3.3V (default) |
| 2-5     | 12V            |

Panel Power control:  
JP3 & JP5 Jump setting



#### 4.3.6. LVDS Backlight Enable Jumper Selection (JP4)

| JP4  | Backlight Power                |
|------|--------------------------------|
| 1-2  | Active High /Convert (default) |
| 2-3* | Active LowNormal               |

#### 4.3.7. Serial Port Mode Switch Setting (SW4, SW5)

RS-232/422/485 Selection (COM1-2 only)

| SW4 (SER1 MODE SEL) |                  |        |        |
|---------------------|------------------|--------|--------|
|                     | RS-232 (default) | RS-422 | RS-485 |
| 1                   | ON*              | ON     | OFF    |
| 2                   | OFF*             | ON     | ON     |

| SW5 (SER2 MODE SEL) |                  |        |        |
|---------------------|------------------|--------|--------|
|                     | RS-232 (default) | RS-422 | RS-485 |
| 1                   | ON*              | ON     | OFF    |
| 2                   | OFF*             | ON     | ON     |

#### 4.3.8. Serial Port Power Selection (JP7, JP8, JP9, JP10)

COM1 Power selection (JP7, JP8)

| JP7 COM1 PWR |      |
|--------------|------|
| 1-2          | +12V |
| 3-4          | +5V  |

| JP8 COM1 PWR |             |
|--------------|-------------|
| 1-2          | GND         |
| 3-4          | RI(Default) |

COM2 Power selection (JP9, JP10)

| JP7 COM1 PWR |      |
|--------------|------|
| 1-2          | +12V |
| 3-4          | +5V  |

| JP8 COM1 PWR |             |
|--------------|-------------|
| 1-2          | GND         |
| 3-4          | RI(Default) |

#### 4.3.9. BIOS Switch Setting (BSW1)

| BSW1                    |                             |                            |
|-------------------------|-----------------------------|----------------------------|
| ON (default)            | 0 (ON)                      | 1 (OFF)                    |
| SEL BIOS<br>(Pos. 1-4)  | Boot from SPI0<br>(default) | Boot from SPI1             |
| BIOS MODE<br>(Pos. 2-3) | Normal BIOS                 | Failsafe BIOS<br>(default) |

#### 4.4. Onboard Connector Information

| Connector      | CN#     | Onboard Connector |                            | Mating Connector    |                             | ADLINK Cable             |
|----------------|---------|-------------------|----------------------------|---------------------|-----------------------------|--------------------------|
|                |         | Manufacturer      | Part No.                   | Manufacturer        | Part No.                    |                          |
| COM Port       | CN29-34 | JVE               | 23N6850-10S10B-01G-B-01    | YOUNG YAK           | YY-1970H-2*5P (PH2.0)       | 30-20876-0000 (optional) |
| ATX power      |         | Molex             | 9359-12P                   | E.C.I               | E.C.I 5016H-2*7P (PH4.2)    | 30-20872-0000 (standard) |
| PS/2 KB/MS     | CN19    | JVE               | 24W1140-06S10-01T-3.4-CS01 | E.C.I               | E.C.I 2020 -06P (PH2.0)     | 30-20873-0000 (optional) |
| USB            | CN40    | JVE               | 23N6850-10S10B-01G-B-V9-01 | YOUNG YAK           | YY-1970H-2*5P (PH2.0)       | 30-20874-1000 (optional) |
| SATA Power     | CN24    | JVE               | 24W1170-05S10-01T-3.4-CS01 | YOUNG YAK           | YY-1970H-2*5P (PH2.0)       | 30-20875-0000 (standard) |
| SATA           | CN22-23 | WIN WIN           | WATM-07DBN4B2B8UW          |                     |                             | 30-10057-0600 (standard) |
| DB-40          |         | Molex             | 502790-4091                |                     |                             | 30-30016-0000 (optional) |
| LVDS           | CN13    | JVE               | FI-X30SSLA-HF              | WELL-LIN ENTERPRISE | WL1058-HL-30P (PH1.0)       |                          |
| LVDS Auxiliary | CN14    | Molex             | 53261-1071                 | WELL-LIN ENTERPRISE | WL1025-H-10P (PH1.25)       |                          |
| Feature        | CN28    | JVE               | 23N6850-28S10B-01G-C-01    | JWT                 | JWT A2005H00-2C*14 (PH2.0)  |                          |
| Audio          | CN16    | JVE               | 23N6850-26S10B-01G-C-01    | JWT                 | JWT A2005H00-2CX13P (PH2.0) |                          |
| Front Panel    | CN27    | JVE               | 23N6850-24S10B-01G-C-01    | YY                  | YY-1970H-2*12P (PH2.0)      |                          |
| eDP            | CN15    | TBD               | TBD                        | TBD                 | TBD                         |                          |

## 5. Smart Embedded Management Agent (SEMA)

The onboard microcontroller (BMC) implements power sequencing and Smart Embedded Management Agent (SEMA) functionality.

The microcontroller communicates via the System Management Bus with the CPU/chipset. The following functions are implemented.

- Total operating hours counter. Counts the number of hours the module has been run in minutes.
- On-time minutes counter. Counts the seconds since last system start.
- Temperature monitoring of CPU and board temperature. Minimum and maximum temperature values of CPU and board are stored in flash.
- Power cycles counter
- Boot counter. Counts the number of boot attempts.
- Watchdog Timer (Type-II). Set / Reset / Disable Watchdog Timer. Features auto-reload at power-up.
- System Restart Cause. Power loss / BIOS Fail / Watchdog / Internal Reset / External Reset
- Fail-safe BIOS support. In case of a boot failure, hardware signals tells external logic to boot from fail-safe BIOS.
- Flash area. 1kB Flash area for customer data
- 128 Bytes Protected Flash area. Keys, IDs, etc. can be stored in a write- and clear-protectable region.
- Board Identify. Vendor / Board / Serial number / Production Date
- Main-current & voltage. Monitors drawn current and main voltages

For a detailed description of SEMA features and functionality, please refer to the SEMA Technical Manual and SEMA Software Manual, downloadable at: [http://www.adlinktech.com/PD/web/PD\\_detail.php?cKind=&pid=1274](http://www.adlinktech.com/PD/web/PD_detail.php?cKind=&pid=1274)

### 5.1. Board Specific SEMA Functions

#### 5.1.1. Voltages

The BMC of the cExpress-BT implements a voltage monitor and samples several onboard voltages. The voltages can be read by calling the SEMA function “Get Voltages”. The function returns a 16-bit value divided into high-byte (MSB) and low-byte (LSB).

| ADC Channel | Voltage Name   | Voltage Formula [V]                 |
|-------------|----------------|-------------------------------------|
| 0           | CPU-Vcore      | (MSB<<8 + LSB) x 3.3 / 1024         |
| 1           | GFX-Vcore      | (MSB<<8 + LSB) x 3.3 / 1024         |
| 2           | +V1.05S        | (MSB<<8 + LSB) x 3.3 / 1024         |
| 3           | Vmem           | (MSB<<8 + LSB) x 3.3 / 1024         |
| 4           | +V1.0V         | (MSB<<8 + LSB) x 3.3 / 1024         |
| 5           | +V3.3V         | (MSB<<8 + LSB) x 1.1 x 3.3 / 1024   |
| 6           | +VIN           | (MSB<<8 + LSB) x 6.000 x 3.3 / 1024 |
| 7           | (MAIN CURRENT) | Use Main Current Function           |

### 5.1.2. Main Current

The BMC of the cExpress-BT implements a current monitor. The current can be read by calling the SEMA function “Get Main Current”. The function returns four 16-bit values divided in high-byte (MSB) and low-byte (LSB). These 4 values represent the last 4 currents drawn by the board. The values are sampled every 250ms. The order of the 4 values is NOT in chronological order. Access by the BMC may increase the drawn current of the whole system. In this case, there are still 3 samples not influenced by the read access.

$$\text{Main Current} = (\text{MSB\_n} \ll 8 + \text{LSB\_n}) \times 8.06\text{mA}$$

### 5.1.3. BMC Status

This register shows the status of BMC controlled signals on the cExpress-BT.

| Status Bit | Signal       |
|------------|--------------|
| 0          | WDT_OUT      |
| 1          | LVDS_VDDEn   |
| 2          | LVDS_BKLTen  |
| 3          | BIOS_MODE    |
| 4          | POSTWDT_DISn |
| 5          | SEL_BIOS     |
| 6          | BIOS_DIS0n   |
| 7          | BIOS_DIS1n   |

### 5.1.4. Exception Codes

In case of an error, the BMC drives a blinking code on the blue Status LED (LED1). The same error code is also reported by the BMC Flags register. The Exception Code is not stored in the Flash Storage and is cleared when the power is removed. Therefore, a “Clear Exception Code” command is not needed or supported.

| Exception Code | Error Message |
|----------------|---------------|
| 0              | NOERROR       |
| 2              | NO_SUSCLK     |
| 3              | NO_SLP_S5     |
| 4              | NO_SLP_S4     |
| 5              | NO_SLP_S3     |
| 6              | BIOS_FAIL     |
| 7              | RESET_FAIL    |
| 8              | POWER_FAIL    |
| 9              | LOW_VIN       |
| 10             | VCORE         |
| 11             | VGFX          |
| 12             | V1P05S        |

| Exception Code | Error Message |
|----------------|---------------|
| 13             | VMEM          |
| 14             | V1P0A         |
| 15             | V3P3A         |
| 16             | +P12V_5V      |
| 18             | CRITICAL_TEMP |
| 19             | NO_CB_PWROK   |
| 20             | NO_HW_PWORK   |
| 21             | NO_V1P24A_PG  |

### 5.1.5. BMC Flags

The BMC Flags register returns the last detected Exception Code since power-up and shows the BIOS in use and the power mode.

| Bit       | Description                              |
|-----------|--|
| [ 0 ~ 4 ] | Exception Code                           |
| [ 6 ]     | 0 = AT mode<br>1 = ATX mode              |
| [ 7 ]     | 0 = Standard BIOS<br>1 = Fail-safe BIOS. |

## 6. System Resources

### 6.1. System Memory Map

| Address Range (decimal)   | Address Range (hex) | Size | Description              |
|---------------------------|---------------------|------|--------------------------|
| (4GB-2MB)                 | FFE00000 – FFFFFFFF | 2 MB | High BIOS Area           |
| (4GB-18MB) – (4GB-17MB-1) | FEE00000 – FEEFFFFF | 1 MB | MSI Interrupts           |
| (4GB-20MB) – (4GB-19MB-1) | FEC00000 – FECFFFFF | 1 MB | APIC Configuration Space |
| 15MB – 16MB               | F00000 – FFFFFF     | 1 MB | ISA Hole                 |
| 1MB -15MB                 | 100000 - EFFFFF     | 14MB | Main Memory              |
| 0K -1MB                   | 00000 – FFFFFF      | 1MB  | DOS Compatibility Memory |

### 6.2. I/O Map

#### 6.2.1. I/O Map

| Hex Range                   | Device  |
|-----------------------------|---|
| 020-02D and 030-03D         | Interrupt controller 1, 8259 equivalent                     |
| 02E-02F                     | Motherboard resource  |
| 040-043 and 050-053         | System Timer  |
| 04E-04F                     | Motherboard resource  |
| 060, 062, 064, 066, 068-06F | 8742 equivalent (keyboard)                                  |
| 061, 063, 065, 067          | NMI control and status                                      |
| 070-077                     | Real Time Clock Controller( bit 7 -NMI mask)                |
| 092                         | Reset (Bit 0)/ Fast Gate A20 (Bit 1)                        |
| 0A0-0B1 and 0B4-0BD         | Interrupt controller 2, 8259 equivalent                     |
| 0B2 and 0B3                 | APM control and status port respectively                    |
| 0E0-0EF                     | Available   |
| 0F0                         | Co-processor error register                                 |
| 2E0-2E7                     | Serial Port 6   |
| 2E0-2E7                     | Serial Port 5   |
| 2E8-2EF                     | Serial Port 4   |
| 2F8-2FF                     | Serial Port 2   |
| 3E8-3EF                     | Serial Port 3   |
| 3F8-3FF                     | Serial Port 1   |
| 378-37F                     | Available   |
| 380-3AF                     | Available   |
| 4D0                         | Master PIC Edge/Level Trigger register                      |
| 4D1                         | Slave PIC Edge/Level Trigger register                       |
| 0A00~0A2F                   | Reserved for SIO functions base address (ex: PME /GPIO etc) |
| CF8-CFB                     | PCI configuration address register (32 bit I/O only)        |
| CF9                         | Reset Control register (8 bit I/O)                          |

| Hex Range | Device                          |
|-----------|---------------------------------|
| CFC-CFF   | PCI configuration data register |
| 1C00      | GPIO Base Address for SB        |
| 1800      | PM (ACPI) Base Address for SB   |
| 1860      | Alias for ICH TCO base address. |
| D000-EFFF | PCIE Root Port                  |
| F000-F03F | VGA                             |
| F040-F05F | Smbus controller                |
| F060-F07F | SATA controller                 |

### 6.2.2. IRQ Lines PIC mode

| IRQ# | Typical Interrupt Resource          | Connected to Pin        | Available |
|------|-------------------------------------|-------------------------|-----------|
| 0    | Counter 0                           | N/A                     | No        |
| 1    | Keyboard controller                 | N/A                     | No        |
| 2    | Cascade interrupt from slave PIC    | N/A                     | No        |
| 3    | Serial Port 2 (COM2)                | IRQ3 via SERIRQ / PIRQ  | Note (1)  |
| 4    | Serial Port 1 (COM1)                | IRQ4 via SERIRQ / PIRQ  | Note (1)  |
| 5    | Serial Port3 (COM3)                 | IRQ5 via SERIRQ / PIRQ  | Note (1)  |
| 6    | Serial Port5 (COM5)                 | IRQ6 via SERIRQ / PIRQ  | No        |
| 7    | Serial Port4 (COM4)                 | IRQ7 via SERIRQ / PIRQ  | Note (1)  |
| 8    | Real-time clock                     | N/A                     | No        |
| 9    | Generic                             | N/A                     | Note (1)  |
| 10   | Serial Port6 (COM6)                 | IRQ10 via SERIRQ / PIRQ | Note (1)  |
| 11   | N/A                                 | N/A                     | Note (1)  |
| 12   | PS/2 Mouse                          | IRQ12 via SERIRQ / PIRQ | Note (1)  |
| 13   | Math Processor                      | N/A                     | Note (1)  |
| 14   | Intel Serio IO GPIO Host Controller | N/A                     | Note (1)  |

Note (1): These IRQs can be used for PCI devices when onboard device is disabled.

### 6.2.3. IRQ Lines APIC mode

| IRQ#   | Typical Interrupt Resource       | Connected to Pin        | Available |
|--------|----------------------------------|-------------------------|-----------|
| 0      | Counter 0                        | N/A                     | No        |
| 1      | Keyboard controller              | N/A                     | No        |
| 2      | Cascade interrupt from slave PIC | N/A                     | No        |
| 3      | Serial Port 2 (COM2)             | IRQ3 via SERIRQ / PIRQ  | Note (1)  |
| 4      | Serial Port 1 (COM1)             | IRQ4 via SERIRQ / PIRQ  | Note (1)  |
| 5      | Serial Port3 (COM3)              | IRQ5 via SERIRQ / PIRQ  | Note (1)  |
| 6      | Serial Port5 (COM5)              | IRQ6 via SERIRQ / PIRQ  | No        |
| 7      | Serial Port4 (COM4)              | IRQ7 via SERIRQ / PIRQ  | Note (1)  |
| 8      | Real-time clock                  | N/A                     | No        |
| 9      | Generic                          | N/A                     | Note (1)  |
| 10     | Serial Port6 (COM6)              | IRQ10 via SERIRQ / PIRQ | Note (1)  |
| 11     | N/A                              | IRQ11 via SERIRQ / PIRQ | Note (1)  |
| 12     | PS/2 Mouse                       | IRQ12 via SERIRQ / PIRQ | Note (1)  |
| 13     | Math Processor                   | N/A                     | Note (1)  |
| 14     | Generic                          | N/A                     | Note (1)  |
| 15     | Intel SD Host Controller         | N/A                     | Note (1)  |
| 54-511 | Microsoft ACPI-Compliant System  | N/A                     | Note (1)  |

Note (1): These IRQs can be used for PCI devices when onboard device is disabled.

### 6.3. PCI Configuration Space Map

| Bus Number | Device Number | Function Number | Routing  | Description                            |
|------------|---------------|-----------------|----------|--|
| 00h        | 00h           | 00h             | N/A      | Intel Host Bridge                      |
| 00h        | 02h           | 00h             | Internal | Intel VGA Controller                   |
| 00h        | 0Eh           | 00h             | Internal | Intel HD Audio Device                  |
| 00h        | 0Fh           | 00h             | Internal | Intel Corporation Communication Device |
| 00h        | 12h           | 00h             | Internal | Intel SATA Controller                  |
| 00h        | 13h           | 00h             | Internal | Intel PCIE Root Port 1                 |
| 00h        | 13h           | 01h             | Internal | Intel PCIE Root Port 2                 |
| 00h        | 13h           | 02h             | Internal | Intel PCIE Root Port 3                 |
| 00h        | 13h           | 03h             | Internal | Intel PCIE Root Port 4                 |
| 00h        | 15h           | 00h             | Internal | Intel USB Controller                   |
| 00h        | 1Bh           | 02h             | Internal | Intel SD Card Controller               |
| 00h        | 1Ch           | 00h             | Internal | Intel eMMC Controller                  |
| 00h        | 1Fh           | 01h             | Internal | Intel SMBUS Controller                 |
| 02h        | 00h           | 00h             | Internal | Intel Ethernet Controller              |
| 03h        | 00h           | 00h             | Internal | Intel Ethernet Controller              |

Note (1): The Bus number would be changed if PEG/PCIE port has device.

## 6.4. PCI Interrupt Routing Map

| INT Line | Audio Controller | xHCI Controller | TXE Controller #1 |
|----------|------------------|-----------------|-------------------|
| Int0     | INTA:25          | INTA:None       | INTA:None         |
| Int1     |                  |                 |                   |
| Int2     |                  |                 |                   |
| Int3     |                  |                 |                   |

| INT Line | PCIE Port 3 | PCIE Port 4 | PCIE Port 5 | PCIE Port 6 |
|----------|-------------|-------------|-------------|-------------|
| Int0     | INTA:22     | INTA:23     | INTA:20     | INTA:21     |
| Int1     | INTB:23     | INTB:20     | INTB:21     | INTB:22     |
| Int2     | INTC:20     | INTC:21     | INTC:22     | INTC:23     |
| Int3     | INTD:21     | INTD:22     | INTD:23     | INTD:20     |

| INT Line | LPC Controller | SATA Controller | SMBus Controller |
|----------|----------------|-----------------|------------------|
| Int0     | INTA:None      | INTA:None       | INTB:None        |
| Int1     |                |                 |                  |
| Int2     |                |                 |                  |
| Int3     |                |                 |                  |

## 6.5. SMBus Slave Address

| Device      | Address |
|-------------|---------|
| DIMM A      | A0h     |
| DIMM B      | A4h     |
| BMC         | 58h     |
| Extend GPIO | 40h     |

## 7. BIOS Setup

### 7.1. Menu Structure

This section presents the six primary menus of the BIOS Setup Utility. Use the following table as a quick reference for the contents of the BIOS Setup Utility. The subsections in this section describe the submenus and setting options for each menu item. The default setting options are presented in bold, and the function of each setting is described in the right hand column of the respective table.

| Main   | Advanced  | Chipset   | Security  | Boot   | Save & Exit  |
|--|---|---|---|--|--|
| <ul style="list-style-type: none"> <li>- BIOS Information</li> <li>- System Information</li> <li>- Board Management ►</li> <li>- System Date</li> <li>- System Time</li> </ul> | <ul style="list-style-type: none"> <li>- CPU Configuration ►</li> <li>- Graphics Configuration ►</li> <li>- Power Management ►</li> <li>- System Management ►</li> <li>- Thermal Management ►</li> <li>- Watchdog Timer ►</li> <li>- CSM Configuration ►</li> <li>- IT8783 Super IO Configuration ►</li> <li>- Serial Console Redirection ►</li> <li>- USB ►</li> <li>- Network ►</li> <li>- Miscellaneous ►</li> <li>- Intel(R) I211 Gigabit Network Connection ►</li> <li>- Intel(R) I211 Gigabit Network Connection ►</li> <li>- Driver Health ►</li> <li>- Trusted Computing ►</li> <li>- AMI Graphic Output Protocol Policy ►</li> <li>- SDIO Configuration ►</li> </ul> | <ul style="list-style-type: none"> <li>- North Bridge ►</li> <li>- South Bridge ►</li> <li>- Uncore Configuration ►</li> <li>- South Cluster Configuration ►</li> </ul> | <ul style="list-style-type: none"> <li>- Setup Administrator Password</li> <li>- User Password</li> <li>- Secure Boot menu ►</li> </ul> | <ul style="list-style-type: none"> <li>- Boot Configuration ►</li> <li>- Boot Option Priorities ►</li> <li>- CSM Parameters ►</li> </ul> | <ul style="list-style-type: none"> <li>- Save Options ►</li> <li>- Default Options ►</li> <li>- Boot Override ►</li> </ul> |

#### Notes:

► indicates a submenu

Gray text indicates info only

## 7.2. Main

The Main Menu provides read-only information about your system and also allows you to set the System Date and Time. Refer to the tables below the screen shot of this menu for details of the submenus and settings.

### 7.2.1. BIOS Information

| Feature             | Options   | Description                        |
|---------------------|-----------|------------------------------------|
| BIOS Vendor         | Info only | Vendor.                            |
| BIOS Version        | Info only | Project BIOS Version               |
| Build Data and Time | Info only | Data and Time                      |
| MRC Version         | Info only | Intel MRC Version                  |
| GOP Version         | Info only | Intel GOP Version                  |
| TXE FW Version      | Info only | Intel TXE FW Version               |
| BIOS Boot Source    | Info only | Display Platform Current Boot BIOS |

### 7.2.2. System Information

| Feature           | Options   | Description                   |
|-------------------|-----------|-------------------------------|
| Project Name      | Info only | Project Name.                 |
| CPU Board Version | Info only | Project Board Version.        |
| CPU Brand String  | Info only | CPU Brand String Information. |
| CPU Frequency     | Info only | CPU Frequency Information.    |
| Total Memory      | Info only | Total memory size.            |
| SOC SKU           | Info only | SOC SKU Information           |

### 7.2.3. Board Information

#### 7.2.3.1. Board Information > Board Information

| Feature            | Options   | Description                  |
|--------------------|-----------|------------------------------|
| Serial Number      | Info only | Display System Serial Number |
| Manufacturing Date | Read only | Display Manufacturing Date   |
| Last Repair Date   | Read only | Display Last Repair Date     |
| MAC ID             | Read only | Display MAC ID               |

#### 7.2.3.2. Board Information > Runtime Statistics

| Feature            | Options   | Description   |
|--------------------|-----------|---|
| Runtime Statistics | Info only |   |
| Total Runtime      | Read only | The returned value specifies the total time in minutes the system is running in S0 state.   |
| Current Runtime    | Read only | The returned value specifies the time in seconds the system is running in S0 state.<br>This counter is cleared when the system is removed from the external power supply. |
| Power Cycles       | Read only | The returned value specifies the number of times the external power supply has been shut down   |
| Boot Cycles        | Read only | The boot counter is increased after a HW- or SW-Reset or after a successful power-up.   |
| Boot Reason        | Read only | The boot reason is the event which causes the reboot of the system.   |

### 7.2.4. System Date and Time

| Feature     | Options             | Description   |
|-------------|---------------------|---|
| System Date | Weekday, MM/DD/YYYY | Requires the alpha-numeric entry of the day of the week, day of the month, calendar month, and all 4 digits of the year, indicating the century and year (Fri XX/XX/20XX) |
| System Time | HH/MM/SS            | Presented as a 24-hour clock setting in hours, minutes, and seconds   |

## 7.3. Advanced

This menu contains the settings for most of the user interfaces in the system.

### 7.3.1. CPU Configuration

| Feature                         | Options                     | Description   |
|---------------------------------|-----------------------------|---|
| CPU Configuration               | Info only                   |   |
| Socket 0 CPU Information        | Submenu                     | Display socket specific CPU Information   |
| Speed                           | Info only                   | Display CPU Speed Frequency   |
| 64-bit                          | Info only                   | Display CPU 64-bit supported  |
| CPU Power Management            | Submenu                     | CPU Power Management options  |
| Active Processor Cores          | Disabled<br>Enabled         | Number of cores to enable in each processor package.  |
| Intel Virtualization Technology | Disabled<br>Enabled         | When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology  |
| VT-d                            | Disabled<br>Enabled         | Enable/Disable CPU VT-d   |
| Bi-direction PROCHOT            | Disabled<br>Enabled         | When a processor thermal sensor trips (either core), the PROCHOT# will be driven. If bi-direction is enabled, external agents can drive PROCHOT# to throttle the processor. |
| Thermal Monitor                 | Disabled<br>Enabled         | Enable/Disable Thermal Monitor.   |
| Monitor Mwait                   | Disabled<br>Enabled<br>Auto | Enable/Disable Monitor Mwait  |
| P-STATE Coordination            | HW_ALL<br>SW_ALL<br>SW_ONLY | Change P-State Coordination type.   |
| DTS                             | Disabled<br>Enabled         | Enabled/Disabled Digital Thermal Sensor.  |

#### 7.3.1.1. CPU Configuration > Socket 0 CPU Information

| Feature                  | Options   | Description                     |
|--------------------------|-----------|---------------------------------|
| Socket 0 CPU Information | Info only |                                 |
| CPU Signature            | Info only | Display CPU Signature           |
| Microcode Patch          | Info only | Display Microcode Patch         |
| Max CPU Speed            | Info only | Display Max CPU Speed           |
| Min CPU Speed            | Info only | Display Min CPU Speed           |
| Processor Cores          | Info only | Display Processor Cores numbers |
| Intel HT Technology      | Info only | Display Not Supported           |
| Intel VT-x Technology    | Info only | Display supported               |
| L1 Data Cache            | Info only | Display L1 Data Cache           |

| Feature       | Options   | Description           |
|---------------|-----------|-----------------------|
| L1 Code Cache | Info only | Display L1 Code Cache |
| L2 Cache      | Info only | Display L2 Cache      |
| L3 Cache      | Info only | Display L3 Cache      |

### 7.3.1.2. CPU Configuration > CPU Power Management

| Feature                            | Options   | Description  |
|------------------------------------|---|--|
| CPU Power Management Configuration | Info only   |  |
| EIST                               | Disabled<br>Enabled   | Enable/Disable Intel SpeedStep   |
| Turbo Mode                         | Disabled<br>Enabled   | Turbo Mode   |
| Boot performance mode              | Max Performance<br>Max Battery  | Select the performance state that the BIOS will set before OS handoff.                           |
| C-States                           | Disabled<br>Enabled   | Enable/Disable C States  |
| Enhanced C-States                  | Disabled<br>Enabled   | Enable/Disable C1E. When enabled, CPU will switch to minimum speed when all cores enter C-State. |
| Max Package C State                | PC2<br>PC1<br>C0  | Controls the Max Package C State that the processor will Support.                                |
| Max Core C State                   | Fused Value<br>Core C10<br>Core C9<br>Core C8<br>Core C7<br>Core C6<br>Core C1<br>Unlimited | This option controls the Max Core C State that cores will support.                               |
| C-State Auto Demotion              | Disabled<br>C1  | Configure C-State Auto Demotion  |
| C-State Auto Un-Demotion           | Disabled<br>C1  | Configure C-State Auto Un-Demotion   |
| Power Limit 1 Enable               | Disabled<br>Enabled   | Enable/Disable Power Limit 1   |
| Power Limit 1                      | Info Only   | Display Power Limit 1 value  |
| Power Limit 1 Clamp Mode           | Disabled<br>Enabled   | Enable/Disable Power Limit 1 Clamp Mode  |
| Power Limit 1 power                | Auto<br>6<br>7<br>8<br>9<br>10<br>11<br>12  | Power Limit 1 in Watts. Auto will program Power Limit 1 based on silicon default support value.  |

| Feature                   | Options  | Description   |
|---------------------------|--|---|
|                           | 13<br>14<br>15<br>16<br>17<br>18<br>19<br>20<br>21<br>22<br>23<br>24<br>25   |   |
| Power Limit 1 Time Window | Auto<br>1<br>2<br>3<br>4<br>5<br>6<br>7<br>8<br>10<br>12<br>14<br>16<br>20<br>24<br>28<br>32<br>40<br>48<br>56<br>64<br>80<br>96<br>112<br>128 | Power Limit 1 Time Window value in Seconds. Auto will program Power Limit 1 Time Window based on silicon default support value. |

### 7.3.2. Graphics Configuration

| Feature                     | Options  | Description                        |
|-----------------------------|--|------------------------------------|
| LVDS                        | Info only  |                                    |
| Data format and Color Depth | VESA 24 bpp<br>JEIDA 24 bpp<br>JEIDA/VESA 18 bpp | Data format and Color Depth select |
| LVDS Output Mode            | Single LVDS bus<br>Dual LVDS bus                 | Single/Dual mode select            |
| DE Polarity                 | Active High<br>Active Low                        | DE Polarity select                 |
| Vsync Polarity              | Active High<br>Active Low                        | Vsync Polarity select              |

| Feature                   | Options                   | Description   |
|---------------------------|---------------------------|---|
| Hsync Polarity            | Active High<br>Active Low | Hsync Polarity select   |
| LVDS Backlight Brightness | Value Range               | A change takes effect immediately. The Value range starts by 0 and ends of 255. |

### 7.3.3. Power Management

| Feature                        | Options                                      | Description  |
|--------------------------------|--|--|
| Enable ACPI Auto Configuration | Disabled<br>Enabled                          | Enable/Disable BIOS ACPI Auto Configuration.   |
| Enable Hibernation             | Disabled<br>Enabled                          | Enable/Disable System ability to hibernate. This option may be not effective with some OS.   |
| ACPI Sleep State               | S3 only (Suspend to RAM)<br>Suspend Disabled | Select ACPI sleep state the system will enter when the SUSPEND button is pressed.  |
| Emulation AT/ATX               | Emulation AT<br>ATX                          | Select Emulation AT or ATX function. If this option set to [Emulation AT], BIOS will report no suspend functions to ACPI OS. Win Windows XP, it will make OS show shutdown message during system shutdown. |
| Lock Legacy Resources          | Disabled<br>Enabled                          | Enables or Disables Lock of Legacy Resources   |
| ECO Mode                       | Disabled<br>Enabled                          | Reduces the power consumption of the system, but after a shut down, you have to wait at least 5 seconds before you can restart the system.   |
| Power Consumption              | Submenu                                      | Power Consumption  |

#### 7.3.3.1. Power Management > Power Consumption

| Feature               | Options   | Description                     |
|-----------------------|-----------|---------------------------------|
| Power Consumption     | Info only |                                 |
| Current Input Current | Read only | Display input current           |
| Current Input Power   | Read only | Display input power             |
| V-CORE                | Read only | Display actual VCORE voltage    |
| VGFX                  | Read only | Display actual VGFX voltage     |
| VMEM                  | Read only | Display actual VMEM voltage     |
| 5VSB                  | Read only | Display actual 5VSB voltage     |
| VIN(12V)              | Read only | Display actual VIN(12V) voltage |
| 5V                    | Read only | Display actual 5V voltage       |
| 3.3V                  | Read only | Display actual 3.3V voltage     |
| 3.3VSB                | Read only | Display actual 3.3VSB voltage   |

### 7.3.4. System Management

| Feature           | Options   | Description                          |
|-------------------|-----------|--------------------------------------|
| System Management | Info only |                                      |
| Version           | Info only | Display Version.                     |
| SEMA Firmware     | Read only | Display SEMA firmware.               |
| Build Date        | Read only | Display SEMA firmware build date     |
| SEMA Boot loader  | Read only | Display SEMA boot loader.            |
| Build Date        | Read only | Display SEMA boot loader build date. |
| SEMA Features     | Submenu   | SEMA Features information            |
| Flags             | Submenu   | SEMA Flags information               |

#### 7.3.4.1. System Management > SEMA Features

| Feature                           | Options   | Description |
|-----------------------------------|-----------|-------------|
| SEMA Supported Features           | Info only |             |
| Uptime & Power Cycles Counter     | Info only |             |
| System Reset Event                | Info only |             |
| 1024 Bytes User-Flash             | Info only |             |
| Watchdog                          | Info only |             |
| Temperatures                      | Info only |             |
| Voltage Monitor                   | Info only |             |
| Display Backlight control         | Info only |             |
| Power-Up Watchdog                 | Info only |             |
| Power Monitor (current sense)     | Info only |             |
| Boot Counter                      | Info only |             |
| Dual-BIOS                         | Info only |             |
| I2C bus 1                         | Info only |             |
| I2C bus 2                         | Info only |             |
| Programmable CPU fan              | Info only |             |
| Programmable System fan           | Info only |             |
| AT/ATX mode                       | Info only |             |
| ACPI Thermal Trigger              | Info only |             |
| Power-Up to last state            | Info only |             |
| Backlight restore                 | Info only |             |
| DTS register available            | Info only |             |
| DTS offset registers programmable | Info only |             |
| TIVA BMC                          | Info only |             |
| PEC Control                       | Info only |             |
| SoftFan                           | Info only |             |
| SEMA Error Log                    | Info only |             |

#### 7.3.4.2. System Management > Flags

| Feature        | Options   | Description                                |
|----------------|-----------|--|
| Flags          | Info only |  |
| BMC Flags      | Read only |  |
| BIOS Select    | Read only | Display the selection of current BIOS ROM. |
| ATX/AT-Mode    | Read only | Display ATX/AT-Mode.                       |
| Exception Code | Read only | System exception reason.                   |

#### 7.3.5. Thermal Management

| Feature                    | Options             | Description   |
|----------------------------|---------------------|---|
| Temperatures and Fan Speed | Submenu             | Temperatures and Fan Speed.   |
| Smart Fan                  | Submenu             | Smart Fan.  |
| Critical Trip Point        | Enabled<br>Disabled | This value is the temperature threshold of the critical trip point. |
| Passive Cooling Trip Point | Enabled<br>Disabled | The time-out value for Control, Bulk, and Interrupt transfers.      |

##### 7.3.5.1. Thermal Management > Temperatures and Fan Speed

| Feature              | Options   | Description                        |
|----------------------|-----------|------------------------------------|
| Temperatures and Fan | Info only |                                    |
| CPU Temperature      | Info only |                                    |
| Current              | Read only | Display current board temperature  |
| Board Temperatures   | Info only |                                    |
| Current              | Read only | Display board current. temperature |
| Startup              | Read only | Display board startup. temperature |
| Min                  | Read only | Display board Min. temperature     |
| Max                  | Read only | Display board Max. temperature     |
| CPU Fan Speed        | Read only | Display CPU Fan RPM                |
| System Fan1 Speed    | Read only | Display System Fan1 RPM            |

##### 7.3.5.2. Thermal Management > Smart Fan

| Feature                          | Options                               | Description                      |
|----------------------------------|---------------------------------------|----------------------------------|
| Smart Fan                        | Info only                             |                                  |
| CPU Smart Fan Temperature Source | CPU Sensor<br>System Sensor           | CPU smart fan temperature source |
| CPU Fan Mode                     | AUTO (Smart Fan)<br>Fan Off<br>Fan On | CPU fan mode                     |

| Feature                             | Options                               | Description                         |
|-------------------------------------|---------------------------------------|-------------------------------------|
| Trigger Point 1                     | Read only                             |                                     |
| Trigger Temperature                 | 40                                    | Trigger Temperature                 |
| PWM Level                           | 30                                    | PWM level                           |
| Trigger Point 2                     | Read only                             |                                     |
| Trigger Temperature                 | 50                                    | Trigger Temperature                 |
| PWM Level                           | 40                                    | PWM level                           |
| Trigger Point 3                     | Read only                             |                                     |
| Trigger Temperature                 | 60                                    | Trigger Temperature                 |
| PWM Level                           | 63                                    | PWM level                           |
| Trigger Point 4                     | Read only                             |                                     |
| Trigger Temperature                 | 70                                    | Trigger Temperature                 |
| PWM Level                           | 100                                   | PWM level                           |
| System Smart Fan1Temperature Source | CPU Sensor<br>Board Sensor            | System Smart Fan1Temperature Source |
| System Fan1 Mode                    | AUTO (Smart Fan)<br>Fan Off<br>Fan On | System Fan1 Mode                    |
| Trigger Point 1                     | Read only                             |                                     |
| Trigger Temperature                 | 15                                    | Trigger Temperature                 |
| PWM Level                           | 30                                    | PWM level                           |
| Trigger Point 2                     | Read only                             |                                     |
| Trigger Temperature                 | 50                                    | Trigger Temperature                 |
| PWM Level                           | 40                                    | PWM level                           |
| Trigger Point 3                     | Read only                             |                                     |
| Trigger Temperature                 | 58                                    | Trigger Temperature                 |
| PWM Level                           | 63                                    | PWM level                           |
| Trigger Point 4                     | Read only                             |                                     |
| Trigger Temperature                 | 65                                    | Trigger Temperature                 |
| PWM Level                           | 100                                   | PWM level                           |

#### 7.3.6. Watchdog Timer

| Feature   | Options             | Description   |
|---|---------------------|---|
| Watchdog Timer  | Info only           |   |
| Power Up watchdog<br>Attention: F12 disables the Power Up Watchdog. | Enabled<br>Disabled | The Power-Up Watchdog resets the system after a certain amount of time after power-up.<br>Pressing F12 during start up disables the power up watchdog |

### 7.3.7. CSM Configuration

| Feature                                    | Options                                     | Description  |
|--|---|--|
| Compatibility Support Module Configuration | Info only                                   |  |
| CSM Support                                | Enabled<br>Disabled                         | Enable/Disable CSM Support   |
| CSM16 Module Version                       | Read Only                                   | Display CSM16 Module Version   |
| GateA20 Active                             | Upon Request<br>Always                      | UPON REQUEST - GA20 can be disabled using BIOS services.<br>ALWAYS - do not allow disabling GA20; this option is useful when any RT code is executed above 1MB |
| Boot option filter                         | UEFI and Legacy<br>Legacy only<br>UEFI only | This option controls Legacy/UEFI ROMs priority   |
| Option ROM execution                       | Info only                                   |  |
| Network                                    | Do not launch<br>UEFI<br>Legacy             | Controls the execution of UEFI and Legacy PXE OpROM  |
| Storage                                    | Do not launch<br>UEFI<br>Legacy             | Controls the execution of UEFI and Legacy Storage OpROM  |
| Video                                      | Do not launch<br>UEFI<br>Legacy             | Controls the execution of UEFI and Legacy Video OpROM  |
| Other PCI device                           | Do not launch<br>UEFI<br>Legacy             | Determines OpROM execution policy for devices other than Network, Storage, or Video.   |

### 7.3.8. IT8783 Super IO Configuration

| Feature                        | Options   | Description                      |
|--------------------------------|-----------|----------------------------------|
| IT8783F Super IO Configuration | Info only |                                  |
| Serial Port 1 Configuration    | Submenu   | Set Parameters of Serial Port 1. |
| Serial Port 2 Configuration    | Submenu   | Set Parameters of Serial Port 2. |
| Serial Port 3 Configuration    | Submenu   | Set Parameters of Serial Port 3. |
| Serial Port 4 Configuration    | Submenu   | Set Parameters of Serial Port 4. |
| Serial Port 5 Configuration    | Submenu   | Set Parameters of Serial Port 5. |
| Serial Port 6 Configuration    | Submenu   | Set Parameters of Serial Port 6. |

### 7.3.8.1. Super IO > Serial Port 1 Configuration

| Feature                     | Options   | Description                                    |
|-----------------------------|---|--|
| Serial Port 1 Configuration | Info only   |  |
| Serial Port                 | Disabled<br>Enabled   | Enable or Disable Serial Port (COM)            |
| Device Setting              | Info only   |  |
| Change Setting              | Auto<br><br>IO=3F8;IRQ=4;<br>IO=3F8;IRQ=3,4,5,7,9,10,11,12<br>IO=2F8;IRQ=3,4,5,7,9,10,11,12<br>IO=3E8;IRQ=3,4,5,7,9,10,11,12<br>IO=2E8;IRQ=3,4,5,7,9,10,11,12 | Select an optimal setting for Super IO Device. |

### 7.3.9. Serial Console Redirection

| Feature                      | Options             | Description  |
|------------------------------|---------------------|--|
| Serial Port Console          | Info only           |  |
| COM1                         | Info only           |  |
| Console Redirection          | Disabled<br>Enabled | Console Redirection enable or disable.   |
| Console Redirection Settings | Submenu             | The settings specify how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings. |
| COM2                         | Info only           |  |
| Console Redirection          | Disabled<br>Enabled | Console Redirection enable or disable.   |
| Console Redirection Settings | Submenu             | The settings specify how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings. |
| COM3                         | Info only           |  |
| Console Redirection          | Disabled<br>Enabled | Console Redirection enable or disable.   |
| Console Redirection Settings | Submenu             | The settings specify how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings. |
| COM4                         | Info only           |  |
| Console Redirection          | Disabled<br>Enabled | Console Redirection enable or disable.   |
| Console Redirection Settings | Submenu             | The settings specify how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings. |
| COM5                         | Info only           |  |
| Console Redirection          | Disabled<br>Enabled | Console Redirection enable or disable.   |
| Console Redirection Settings | Submenu             | The settings specify how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings. |

| Feature                      | Options             | Description  |
|------------------------------|---------------------|--|
| COM6                         | Info only           |  |
| Console Redirection          | Disabled<br>Enabled | Console Redirection enable or disable.   |
| Console Redirection Settings | Submenu             | The settings specify how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings. |

#### 7.3.9.1. Serial Console Redirection > Console Redirection Settings

| Feature                              | Options   | Description   |
|--------------------------------------|---|---|
| COM0<br>Console Redirection Settings | Info only   |   |
| Terminal Type                        | VT100<br>VT100+<br>VT-UTF8<br>ANSI                | VT100: ASCII char set.<br>VT100+: Extends VT100 to support color, function keys, etc.<br>VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes.<br>ANSI: Extended ASCII char set. |
| Bits per second                      | 9600<br>19200<br>38400<br>57600<br>115200         | Selects serial port transmission speed. The speed must be matched on the remote computer. Long or noisy lines may require lower speeds.   |
| Data Bits                            | 7<br>8  | Select data bits.   |
| Parity                               | None<br>Even<br>Odd<br>Mark<br>Space              | Select parity.  |
| Stop Bits                            | 1<br>2  | Select number of stop bits.   |
| Flow Control                         | None<br>Hardware RTS/CTS                          | Select flow control.  |
| VT-UTF8 Combo Key Support            | Disabled<br>Enable                                | Enable VT-UTF8 combination key support for ANSI/VT100 terminals.  |
| Recorder Mode                        | Disabled<br>Enable                                | With this mode enabled only text will be sent. This is to capture terminal data.  |
| Resolution 100x31                    | Disabled<br>Enable                                | Enables or disables extended terminal resolution  |
| Legacy OS Redirection                | 80x24<br>80x25                                    | On legacy OSes, the number of rows and columns supported by redirection   |
| Putty KeyPad                         | VT100<br>LINUX<br>XTERMR6<br>SCO<br>ESCN<br>VT400 | Select Function Key and KeyPad on Putty.  |
| Redirection After BIOS Post          | Always Enabled<br>BootLoader                      | The Settings specify if BootLoader is selected, then legacy console redirection is disabled before booting to legacy OS.  |

### 7.3.10. USB

| Feature                            | Options                              | Description   |
|------------------------------------|--------------------------------------|---|
| USB Module version                 | Info only                            |   |
| USB Controllers:                   | Info only                            |   |
| USB Devices:                       | Info only                            |   |
| Legacy USB Support                 | Enabled<br>Disabled                  | Enables Legacy USB support.   |
| XHCI Hand-off                      | Disabled<br>Enabled                  | This is a workaround for OSes without XHCI hand-off support.                                |
| USB Mass Storage Driver Support    | Enabled<br>Disabled                  | Enable/Disable USB Mass Storage Driver Support.   |
| USB hardware delays and time-outs: | PCH USB Configuration                |   |
| USB transfer time-out              | 1 sec<br>5 sec<br>10 sec<br>20 sec   | The time-out value for Control, Bulk, and Interrupt transfers.                              |
| Device reset time-out              | 10 sec<br>20 sec<br>30 sec<br>40 sec | USB mass storage device start unit command time-out.  |
| Device power-up delay              | Auto<br>Manual                       | Maximum time the device will take before it properly reports itself to the host controller. |
| USB Storage Devices:               | Info Only                            |   |

### 7.3.11. Network

| Feature                | Options             | Description  |
|------------------------|---------------------|--|
| Onboard LAN Controller | Disabled<br>Enabled | Enable/Disable onboard Intel I210LM LAN Controller.. |
| Network Stack          | Disabled<br>Enabled | Enable/Disable UEFI Network Stack..                  |

### 7.3.12. Miscellaneous

| Feature                   | Options             | Description                |
|---------------------------|---------------------|----------------------------|
| Chassis Intrusion Support | Disabled<br>Enabled | Chassis Intrusion Support. |

### 7.3.13. Trusted Computing

| Feature                 | Options             | Description  |
|-------------------------|---------------------|--|
| Security Device Support | Disabled<br>Enabled | Enables or Disables BIOS support for security device. O.S. will not show security Device. TCG EFI protocol and INT1A interface will not be available |

### 7.3.14. AMI Graphic Output Protocol Policy

| Feature                      | Options   | Description       |
|------------------------------|-----------|-------------------|
| Intel(R) Graphics Controller | Info only |                   |
| Intel(R) GOP Driver []       | Read Only |                   |
| Output Select                | DP2       | Output Interface. |

### 7.3.15. SDIO Configuration

| Feature            | Options                     | Description   |
|--------------------|-----------------------------|---|
| SDIO Configuration | Info only                   |   |
| SDIO/GPIO Mode     | GPIO Mode<br>SDIO Mode      | Select SDIO or GPIO function.   |
| SDIO Access Mode   | Auto<br>ADMA<br>SDMA<br>PIO | Auto Option: Access SD device in DMA mode if controller supports it, otherwise in PIO mode. DMA Option: Access SD device in DMA mode. PIO Option: Access SD device in PIO Mode. |

## 7.4. Chipset

| Feature                     | Options | Description                 |
|-----------------------------|---------|-----------------------------|
| North Bridge                | Submenu | North Bridge Parameters     |
| South Bridge                | Submenu | South Bridge Parameters     |
| Uncore Configuration        | Submenu | Uncore Configuration.       |
| South Cluster Configuration | Submenu | South Cluster Configuration |

### 7.4.1. North Bridge

| Feature                        | Options                                      | Description   |
|--------------------------------|--|---|
| Memory Information             | Info Only                                    |   |
| Total memory                   | Read Only                                    | Display Memory Size information   |
| Memory Voltage                 | Read Only                                    | Display Memory voltage  |
| Memory Slot0                   | Read Only                                    | Display Memory Slot0 information  |
| Memory Slot1                   | Read Only                                    | Display Memory Slot1 information  |
| Max TOLUD                      | 2 GB<br>2.25 GB<br>2.5 GB<br>2.75 GB<br>3 GB | Maximum Value of TOLUD  |
| Above 4GB MMIO BIOS assignment | Disable<br>Enable                            | Enable/Disable above 4GB memory mapped IO BIOS assignment.<br>This is disable automatically when Aperture Size is set to 2048MB |
| PCIE VGA Workaround            | Disable<br>Enable                            | Enable it if your PCIe card cannot boot to DOS. This is for Test only.  |

### 7.4.2. South Bridge

| Feature          | Options   | Description   |
|------------------|---|---|
| Serial IRQ Mode  | Quiet<br>Continuous   | Configure Serial IRQ Mode   |
| SMBus Support    | Disable<br>Enable   | Enable/Disable SMBus Support                                      |
| OS Selection     | Windows<br>Android<br>Win7<br>Intel Linux                           | Select the target OS.   |
| PCI CLOCK RUN    | Disable<br>Enable   | Enable CLKRUN# logic to stop PCI clocks.                          |
| Real Time Option | RT Disabled<br>RT Enabled, Agent ID11<br>RT Enabled, Agent Disabled | Select Real-Time Enable and IDI Agent Real-Time traffic Mask Bits |

### 7.4.3. Uncore Configuration

#### 7.4.3.1. Uncore Configuration > GOP Configuration

| Feature              | Options  | Description  |
|----------------------|--|--|
| Active LFP Config    | No LFP<br>eDP  | Active Local Flat Panel Config   |
| LVDS Backlight Mode  | GTT Mode<br>BMC Mode   | Select LVDS Backlight control function.  |
| DDI Port 1           | No Device<br>Display Port<br>HDMI<br>DisplayPort with HDMI/DVI<br>Compatible   | DDI port 1 function choose to display Port or HDMI   |
| DDI Port 2           | No Device<br>Display Port<br>HDMI<br>DisplayPort with HDMI/DVI<br>Compatible   | DDI port 2 function choose to display Port or HDMI   |
| LCD Panel Type       | Auto<br>640x480<br>800x600<br>1024x768<br>1280x1024<br>1400x1050(RB) LVDS1<br>1400x1050 LVDS2<br>1600x1200 LVDS<br>1366x768 LVDS<br>1680x1050<br>1920x1200<br>1440x900 LVDS<br>1600x900 LVDS<br>1024x768 LVDS2<br>1280x800<br>1920x1080 LVDS<br>2048x1536 LVDS | Select LFP panel used by Internal Graphics Device by selecting the appropriate setup item. |
| GOP Brightness level | Value  | Set GOP Brightness Level1; Value ranges from 0-255   |

#### 7.4.3.2. Uncore Configuration > IGD Configuration

| Feature                    | Options                 | Description   |
|----------------------------|-------------------------|---|
| IGD Configuration          | Info only               |   |
| Integrated Graphics Device | Enabled<br>Disabled     | Enable: Enable Integrated Graphics Device (IGD) when selected as the Primary Video Adaptor. Disable: Always disable IGD |
| Primary Display            | IGD<br>PCIE<br>HG       | Select which of IGD/PCI Graphics device should be Primary Display.  |
| Aperture Size              | 128MB<br>256MB<br>512MB | Select the Aperture Size.   |

| Feature            | Options   | Description  |
|--------------------|---|--|
| DVMT Pre-Allocated | 64MB<br>96MB<br>128MB<br>160MB<br>192MB<br>224MB<br>256MB<br>288MB<br>320MB<br>352MB<br>384MB<br>416MB<br>448MB<br>480MB<br>512MB | Select DVMT 5.0 Pre-Allocated (Fixed) Graphics Memory size used by the Internal Graphics Device. |
| DVMT Total Gfx Mem | 128M<br>256M<br>MAX   | Select DVMT5.0 Total Graphic Memory size used by the Internal Graphics Device.                   |

#### 7.4.4. South Cluster Configuration

| Feature                   | Options | Description  |
|---------------------------|---------|--|
| HD-Audio Configuration    | Submenu | HD-Audio Configuration Settings                                      |
| PCI Express Configuration | Submenu | PCI Express Configuration Settings                                   |
| SATA Devices              | Submenu | Press <Enter>.to select the SATA Device Configuration Setup options. |
| SCC Configuration         | Submenu | SCC Configuration Settings   |
| USB Configuration         | Submenu | USB Configuration Settings   |
| Miscellaneous             | Submenu | Enable/Disable Misc. Features  |

##### 7.4.4.1. South Cluster Configuration > HD-Audio Configuration

| Feature                | Options             | Description                     |
|------------------------|---------------------|---------------------------------|
| HD-Audio Configuration | Info only           |                                 |
| HD-Audio Support       | Disabled<br>Enabled | Enable/Disable HD-Audio Support |

##### 7.4.4.2. South Cluster Configuration > PCI Express Configuration

| Feature                 | Options             | Description   |
|-------------------------|---------------------|---|
| PCIe Configuration      | Info only           |   |
| Compliance Mode         | Disabled<br>Enabled | Compliance Mode Enable/Disable  |
| PCIe Express Root Port3 | Submenu             | Control the PCI Express Root Port.<br>Auto: To disable unused root port automatically for the most optimum power savings.<br>Enable: Enable PCIE root port<br>Disable: Disable PCIE root port |

| Feature                 | Options | Description   |
|-------------------------|---------|---|
| PCIe Express Root Port4 | Submenu | Control the PCI Express Root Port.<br>Auto: To disable unused root port automatically for the most optimum power savings.<br>Enable: Enable PCIE root port<br>Disable: Disable PCIE root port |
| PCIe Express Root Port5 | Submenu | Control the PCI Express Root Port.<br>Auto: To disable unused root port automatically for the most optimum power savings.<br>Enable: Enable PCIE root port<br>Disable: Disable PCIE root port |
| PCIe Express Root Port6 | Submenu | Control the PCI Express Root Port.<br>Auto: To disable unused root port automatically for the most optimum power savings.<br>Enable: Enable PCIE root port<br>Disable: Disable PCIE root port |

### South Cluster Configuration > PCI Express Configuration > PCIe Express Root Port3

| Feature                 | Options  | Description   |
|-------------------------|--|---|
| PCIe Express Root Port3 | Disabled<br>Enabled  | Control the PCI Express Root Port.<br>Auto: To disable unused root port automatically for the most optimum power savings.<br>Enable: Enable PCIE root port<br>Disable: Disable PCIE root port |
| ASPM                    | Disable<br>L0s<br>L1<br>L0sL1<br>Auto  | PCI Express Active State Power Management settings.   |
| L1 Substates            | Disable<br>L1.1<br>L1.2<br>L1.1 & L1.2                                       | PCI Express L1 Substates Settings   |
| ACS                     | Disabled<br>Enabled  | Enable/Disable Access Control Services Extend Capability.   |
| URR                     | Disabled<br>Enabled  | PCI Express Unsupported Request Reporting Enable/Disable .  |
| FER                     | Disabled<br>Enabled  | PCI Express Device Fatal Error Reporting Enable/Disable .   |
| NFER                    | Disabled<br>Enabled  | PCI Express Device Non-Fatal Error Reporting Enable/Disable.  |
| CER                     | Disabled<br>Enabled  | PCI Express Device Correctable Error Reporting Enable/Disable .   |
| CTO                     | Default Setting<br>16-55 ms<br>65-210 ms<br>260-900 ms<br>1-3.5 s<br>Disable | PCI Express Completion Timer To Enable/Disable  |
| SEFE                    | Disabled<br>Enabled  | Root PCI Express System Error on Fatal Error Enable/Disable .   |

| Feature                     | Options                   | Description   |
|-----------------------------|---------------------------|---|
| SENFE                       | Disabled<br>Enabled       | Enable or disable Root PCI Express System Error on Non-Fatal Error.   |
| SECE                        | Disabled<br>Enabled       | Root PCI Express System Error on Correctable Error Enable/Disable.  |
| PME SCI                     | Disabled<br>Enabled       | PCI Express PME SCI Enable/Disable.   |
| Hot Plug                    | Disabled<br>Enabled       | PCI Express Hot Plug Enable/Disable.  |
| PCIe Speed                  | Auto<br>Gen1<br>Gen2      | Configure PCIe Speed.   |
| Transmitter Half Swing      | Disabled<br>Enabled       | Transmitter Half Swing Enable/Disable.  |
| Extra Bus Reserved          | 0                         | Extra Bus Reserved (0-7) for bridges behind this Root Bridge.   |
| Reserved Memory             | 10                        | Reserved Memory and Prefetchable memory (1-20MB) Range for this Root Bridge.  |
| Reserved I/O                | 4                         | Reserved I/O (4K/8K/12K/46K/20K) Range for this Root Bridge.  |
| PCH PCIE LTR                | Disabled<br>Enabled       | PCH PCIE Latency Reporting Enable/Disable.  |
| Snoop Latency Override      | Disable<br>Manual<br>Auto | Snoop Latency Override for PCH PCIE.<br>Disable: Disable override.<br>Manual: Manually enter override values<br>Auto (Default): Maintain default BIOS flow.     |
| Non Snoop Latency Override  | Disable<br>Manual<br>Auto | Non Snoop Latency Override for PCH PCIE.<br>Disable: Disable override.<br>Manual: Manually enter override values<br>Auto (Default): Maintain default BIOS flow. |
| PCIE LTR Lock               | Disabled<br>Enabled       | PCIE LTR Configuration Lock.  |
| PCIe Selectable De-emphasis | Disabled<br>Enabled       | When the Link is operating at 5.0 GT/s speed, this bit selects the level of de-emphasis for an Upstream component.<br>1b – 3.5 dB<br>0b – 6 dB.                 |

#### 7.4.4.3. South Cluster Configuration > SATA Devices

| Feature                               | Options              | Description  |
|---------------------------------------|----------------------|--|
| SATA Drives                           | Info only            |  |
| Chipset-SATA Controller Configuration | Info only            |  |
| Chipset SATA                          | Disabled<br>Enabled  | Enable/Disable the Chipset SATA Controller. The Chipset SATA Controller supports 2 black internal SATA ports (up to 3Gb/s supported per port). |
| SATA Mode Selection                   | AHCI                 | Determines how SATA Controller(s) operate.   |
| SATA Interface Speed                  | Gen1<br>Gen2<br>Gen3 | Select SATA Interface Speed, CHV A1 always with Gen1 Speed.  |

| Feature                         | Options                              | Description   |
|---------------------------------|--------------------------------------|---|
| SATA Test Mode                  | Disabled<br>Enabled                  | Test mode Enabled / Disabled  |
| Aggressive LPM Support          | Disabled<br>Enabled                  | Enable PCH to aggressively enter link power state.  |
| SATA Port Configuration         | Submenu                              | SATA Device Options Settings.   |
| SATA Port 0                     | Info only                            |   |
| Software Preserve               | Info only                            |   |
| Port 0                          | Disabled<br>Enabled                  | Enable or Disable SATA Port.  |
| SATA Port 0 Hot Plug Capability | Disabled<br>Enabled                  | If enabled, SATA port will be reported as Hit Plug capable.   |
| Configured as eSATA             | Info only                            |   |
| Mechanical Preserve Switch      | Disabled<br>Enabled                  | Controls reporting if this port has an Mechanical Preserve Switch.<br>Note: Requires hardware support.  |
| Spin Up Device                  | Enabled<br>Disabled                  | If enable for any ports Staggered Spin Up will be performed and only the drives which have this option enabled will spin up at boot.<br>Otherwise all drives spin up at boot. |
| SATA device Type                | Hard Disk Drive<br>Solid State Drive | Identify the SATA port is connected to solid state drive or Hard Disk drive   |
| SATA port 0 DevSlp              | Disabled<br>Enabled                  | Enable/Disable SATA Port 0 DevSlp. Board rework for LP needed before enable.  |
| DITO Configuration              | Disabled<br>Enabled                  | Enable/Disable DITO Configuration.  |
| DITO Value                      | Read Only                            |   |
| DM Value                        | Read Only                            |   |

#### 7.4.4.4. South Cluster Configuration > SCC Configuration

| Feature                      | Options             | Description                        |
|------------------------------|---------------------|------------------------------------|
| SCC SD Card Support (D27:F0) | Disabled<br>Enabled | Enable/Disable SCC SD Card Support |

#### 7.4.4.5. South Cluster Configuration > USB Configuration

| Feature                   | Options             | Description  |
|---------------------------|---------------------|--|
| XHCI Pre-Boot Driver      | Disabled<br>Enabled | Enable/Disable XHCI Pre-Boot Driver Support  |
| XHCI Mode                 | Disabled<br>Enabled | Once disable, XHCI controller would be function disabled, none of the USB devices are detectable and usable during boot and in OS. Do not disable it unless for debug purpose. |
| USB Port Disable Override | Disabled<br>Enabled | Selectively Enable/Disable the corresponding USB port from reporting a Device Connection to the controller.  |
| USB Port #0               | Disabled<br>Enabled | Enable/Disable USB port. Once disabled, any USB devices plug into the connector will not be detected by BIOS or OS.  |

#### 7.4.4.6. South Cluster Configuration > Miscellaneous

| Feature              | Options                            | Description   |
|----------------------|------------------------------------|---|
| High Precision Timer | Disabled<br>Enabled                | Enable or Disable the High Precision Event Timer  |
| State After G3       | S0 State<br>S5 State<br>Last State | Specify what state to go to when power is re-applied after a power failure (G3 State).<br><br>S0 State: System will boot directly as soon as power applied.<br>S5 State: System keeps in power-off state until power button is pressed. |
| Wake on LAN          | Disabled<br>Enabled                | Enable or Disable the Wake on LAN   |

## 7.5. Security

### 7.5.1. Password Description

| Feature                      | Options        | Description                        |
|------------------------------|----------------|------------------------------------|
| Setup Administrator Password | Enter password |                                    |
| User Password                | Enter password |                                    |
| Secure Boot menu             | Submenu        | Customizable Secure Boot settings. |

#### 7.5.1.1. Secure Boot Menu

| Feature             | Options             | Description  |
|---------------------|---------------------|--|
| System Mode         | Setup               |  |
| Secure Boot         | Info only           |  |
| Vendor Boot         | Info only           |  |
| Secure Boot Control | Disabled<br>Enabled | Secure Boot can be enabled if:<br>1. System running in User mode with enrolled Platform Key (PK)<br>2. CSM function is disabled. |

## 7.6. Boot

### 7.6.1. Boot Configuration

| Feature                | Options   | Description   |
|------------------------|---|---|
| Boot Configuration     | Info only   |   |
| Setup Prompt Timeout   | 1   | Number of seconds to wait for setup activation key. 65535 (0xFFFF) means indefinite waiting.    |
| Bootup NumLock State   | On<br>Off   | Select the keyboard NumLock state.  |
| Quiet Boot             | Disabled<br>Enabled   | Enable or disables Quiet Boot option.   |
| Fast Boot              | Disabled<br>Enabled   | Enable or Disable Fast Boot features. Most probes are skipped to reduce time cost during boot.. |
| New Boot Option Policy | Default<br>Place First<br>Place Last  | Controls the placement of newly detected UEFI boot options                                      |
| Boot Mode select       | Legacy<br>UEFI  | Select boot mode LEGACY/UEFI  |
| Boot Option #1~ #8     | Hard Disk<br>CD/DVD<br>USB Hard Disk<br>USB CD/DVD<br>USB Key<br>USB Floppy<br>USB LAN<br>Network<br>Disabled | Set the system boot order   |

## Safety Instructions

Read and follow all instructions marked on the product and in the documentation before you operate your system. Retain all safety and operating instructions for future use.

- Please read these safety instructions carefully.
- Please keep this User's Manual for later reference.
- Read the specifications section of this manual for detailed information on the operating environment of this equipment.
- When installing/mounting or uninstalling/removing equipment, turn off the power and unplug any power cords/cables.
- To avoid electrical shock and/or damage to equipment:
  - Keep equipment away from water or liquid sources.
  - Keep equipment away from high heat or high humidity.
  - Keep equipment properly ventilated (do not block or cover ventilation openings).
  - Make sure to use recommended voltage and power source settings.
  - Always install and operate equipment near an easily accessible electrical socket-outlet.
  - Secure the power cord (do not place any object on/over the power cord).
  - Only install/attach and operate equipment on stable surfaces and/or recommended mountings.
  - If the equipment will not be used for long periods of time, turn off and unplug the equipment from its power source.
- Never attempt to fix the equipment. Equipment should only be serviced by qualified personnel.

A Lithium-type battery may be provided for uninterrupted, backup or emergency power.



Risk of explosion if battery is replaced with one of an incorrect type. Dispose of used batteries according to their instructions.

---

### CAUTION

---

- Equipment must be serviced by authorized technicians when:
  - The power cord or plug is damaged;
  - Liquid has penetrated the equipment;
  - It has been exposed to high humidity/moisture;
  - It is not functioning or does not function according to the user's manual;
  - It has been dropped and/or damaged; and/or,
  - It has an obvious sign of breakage.

## Getting Service

Ask an Expert: <http://askanexpert.adlinktech.com>

### **ADLINK Technology, Inc.**

Address: 9F, No.166 Jian Yi Road, Zhonghe District  
New Taipei City 235, Taiwan  
Tel: +886-2-8226-5877  
Fax: +886-2-8226-5717  
Email: [service@adlinktech.com](mailto:service@adlinktech.com)

### **Ampro ADLINK Technology, Inc.**

Address: 5215 Hellyer Avenue, #110, San Jose, CA 95138, USA  
Tel: +1-408-360-0200  
Toll Free: +1-800-966-5200 (USA only)  
Fax: +1-408-360-0222  
Email: [info@adlinktech.com](mailto:info@adlinktech.com)

### **ADLINK Technology (China) Co., Ltd.**

Address: 300 Fang Chun Rd., Zhangjiang Hi-Tech Park, Pudong New Area  
Shanghai, 201203 China  
Tel: +86-21-5132-8988  
Fax: +86-21-5132-3588  
Email: [market@adlinktech.com](mailto:market@adlinktech.com)

### **ADLINK Technology GmbH**

Address: Hans-Thoma-Strasse 11, D-68163, Mannheim, Germany  
Tel: +49-621-43214-0  
Fax: +49-621 43214-30  
Email: [emea@adlinktech.com](mailto:emea@adlinktech.com)

Please visit the Contact page at [www.adlinktech.com](http://www.adlinktech.com) for information on how to contact the ADLINK regional office nearest you.